

# caroma®

CI/SfB	(74.8)	n6
Date	June 2012	

Supersedes all previous issues

## Cube Back-to-Wall

# 9.02.2

### Acrylic Bath

Nominal Sizes: 1600mm x 850mm x 572mm

1750mm x 850mm x 572mm



# Cube Back-to-wall

## Acrylic Bath

1600mm x 850mm x 572mm

1750mm x 850mm x 572mm



The bath for anyone that thinks outside the square. Ultra modern with bold geometrics softened by rounded corners, this is a semi-freestanding bath for those who love the look of freestanding but don't have the space. The thinner rim profile is sleek and in line with European designer trends. Complete the look with matching Cube basins and toilet suite.

1600mm long x 850mm wide x 572mm deep – standard Code No.CU6WFW

1750mm long x 850mm wide x 572mm deep – standard Code No.CU8WFW

**Durability:** Sanitaryware grade acrylic resists chipping, will not rust and has excellent heat retention properties. Its high gloss finish has natural slip resistance. Minor scratch marks can be removed with gentle metal polishes, such as Brasso.

**Waste Outlet:** The reinforced waste outlet is suitable for 40mm diameter standard waste assembly.

**Bath Capacity:** Cube 1600 Back to Wall - 375 litres; Cube 1800 Back to Wall - 416 litres

**Installation:** The bath is suitable for Back to Wall freestanding bath installations. Refer to Installation Instruction for further installation information.

**Colours:** White only.

**Dimensions:** All dimensions are in millimetres and are subject to normal manufacturing variations. Caroma pursues a policy of continuing improvement in design and performance of its products. The right is therefore reserved to vary specifications without notice.

Build and waterproof wall to provide 10-15mm deep cavity on the wall for the tiling flange side of the bath

Wall  
Virlaboard  
Silicone

### Flexible Connector Installation

#### Free Standing Bath with Footlockers

Wall

Back feet with footlocker  
Front feet

Front of Bath where normally entered from.

Simply drill and secure the foot lockers to the floor where the two back feet of the bath will be positioned upon installation.

#### BRICK

Brick wall  
Approved tile backing  
Virlaboard  
Tiles  
Waterproof membrane  
Bathroom silicone sealant  
Bath

Finish the wall to Building codes and Local Authority requirements

#### TIMBER FRAMING

(All timber should not be less than grade F4, with moisture less than 15%)

Timber wall stud  
Virlaboard  
Approved tile backing  
Waterproof membrane  
Tiles  
Bathroom silicone sealant  
Bath

Apply silicone around the bath base surrounding, leaving a 20mm gap in an inconspicuous position.

#### Foot installation to footlocker.

Footbolt

Bath Foot  
Footlocker  
Screw  
Floor

Slide the bath into position for the back feet to glide under and into the footlockers. Make sure that the flexible connector is not kinked upward upon installation, as this will result in drainage issues.

Bath

Flexible Connector  
Waste Trap  
Floor

IMPORTANT: Local Authorities have varying installation requirements, check with Authority or your Caroma representative for further details.