experience function quality style technology



GRAB RAIL MANUAL



SYMBOLS

Con-Serv® symbols are designed to give assistance to healthcare providers in selecting the most suitable grab rail option for people with disabilities.



CLAM FLANGE®

This symbol confirms the grab rail as represented is manufactured with a pre-formed 78mm snap on domed cover with a 5 degree radius to comply with clause 17 of AS 1428.1-2009 for Design and Construction. FFATURES & BENFEITS PAGE 25



HYGIENIC SEAL®

This symbol confirms the grab rail as represented is fabricated with Con-Serv's own 50mm (TPE) fitted flange Hygienic Seal®. The flange is designed with a 5 degree radius to comply with clause 17 of AS 1428.1-2009 for Design and Construction. FEATURES & BENEFITS PAGE 32



LINEAR

This symbol confirms the grab rail as represented is fabricated with Con-Serv's "T" leg Linear flange. The flange is designed with a 5° radius to comply with clause 17 of AS 1428.1-2009 for Design and Construction. FEATURES & BENEFITS PAGE 33



AMBULANT TOILET COMPLIANT

This symbol when exhibited, confirms that the grab rail complies with the requirements of AS 1428.1 2009 for installation in Sanitary Compartments for People with Ambulant Disabilities.



DIMENSIONAL COMPLIANT

This symbol when exhibited confirms that the item complies with the dimensional requirements of AS 1428.1-2009 for installation where applicable in water closets. 2 walled shower enclosure.



PWD SHOWER COMPLIANT - 2

This symbol when exhibited, confirms that the grab rail handshower kit complies strictly with all requirements of AS 1428.1-2009 for a 2 walled shower enclosure for People with Disabilities (PWD).



PAPER ZONE COMPLIANT

This symbol when exhibited confirms that the item complies with the positional requirements of AS 1428.1-2009 for a paper dispenser zone.

® and TM

Indicate trademarks of Con-Serv Corporation Australia Ptv Ltd.



Warranty on all mechanical parts from manufacturing defects in materials and workmanship under normal use in a domestic installation for as long as the original purchaser owns their home into which the particular product(s) was/were installed. A five year warranty (also on the terms below) will apply to commercial installations, irrespective of ownership.

Con-Serv will repair or replace defective items correctly installed as per the Con-Serv installation instructions. Con-Serv will not be liable for defects arising through normal wear and tear. Item(s) must be returned with proof of purchase to Con-Serv at 17 Glentanna Street, Kedron, Queensland 4031. We will attend to your warranty claim after we make appropriate investigations. Contact our Service Manager during normal office hours on 1300 467 322 or at our email address of warranty@con-serv.com.au. If a warranty claimis accepted, Con-Serv will bear the reasonable





costs of the return of the defective item(s) to us. A claim for expenses associated with making a claim for a defective product must be in writing and submitted to us with copies of supporting documents. The benefits given under our warranty are in addition to other rights and remedies of the customer under a law in relation to goods and services to which this warranty relates. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or a refund for a major failure and compensation for any other reasonable foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. Visit the Con-Serv website www.con-serv.com.au for the detailed warranty policy.



Bathrooms

Bathroom Accessories - Modena Collection	2-3
Bathroom Accessories - Comfort Collection	4-7
Bathroom Baskets	8
Bathroom Rails - 25mm Comfort Collection	9
Shower Systems For Healthcare Applications	
Hosfab® - PWD Independent Accessible Shower Kits	11
Hosfab® - Commercial Shower Options	12-15

Hosfab® - Home Care Shower Selections16-17Hosfab® - Premium Shower Selections18-20Hosfab® - Premium Linear Shower Selections21



Grab Rails

Safe-Assist® - Clam Flange® - Straight / Free Standing Grab Rails	26-27
Safe-Assist® - Clam Flange® - Shower Recess Grab Rails	29
Safe-Assist® - Hygienic Seal® - Linear Grab Rail Options	31
Safe-Assist® - Hygienic Seal® - Straight Grab Rails	32-33
Safe-Assist® - Hygienic Seal® - 40° and 90° Toilet Assist Grab Rails	34-35
Safe-Assist® - Hygienic Seal® - Corner Grab Rails	36
Safe-Assist® - Hygienic Seal® - Shower Recess Grab Rails	37
Safe-Assist® - Hygienic Seal® - Grab Rail with Towel Rail "D" & "U" Shape	38
Safe-Assist® - Hygienic Seal® - Grab Rail with Paper Holder Combinations	39
Safe-Assist® - Tiltlock® - Lock-Up / Lock-Down Folding Rail-Ways®	40
Safe-Assist® - Swinglock® - Side Swing Grab Rail	41
Safe-Assist® - Folding Shower Seats	42-43
Safe-Assist® - Backrest Toilet Support Options	44-45
Safe-Assist® - Anti-Ligature Grab Rails	46-47
Hygienic Seal® Multi-purpose / Fixing Systems	48-49
Hideaway™ Seat Mount Systems	50
Hideaway™ Grab Rail Mount Systems	51
Rail-Ways® - Accessories	52-53

Technical Product Information

Clam Flange® Information Page	23
Hygienic Seal® Information Page	30
Circulation Space in Toilets/Water Closets	54
Options for Use in Toilets/Water Closets	55
Systems for PWD - 2 Walled Shower Enclosure	56
Options for Use in 2 Walled Shower Enclosure	57
Systems for PWD - To Suit Combined Sanitary Compartment	58
Options for PWD - To Suit Combined Sanitary Compartment	59
Stainless Steel Information Page	22
Warranty	Inside front cover

AVAILABILITY

The items shown in this manual are generally ex-stock. For custom made configuration grab rails, allow 10 working days for fabrication and delivery. Returns and credit facilities are not available for these models.

COPYRIGHT

This document is Standards Australia Ltd copyrighted material that is distributed by SAI Global on Standards Australia Ltd's behalf. It may be reproduced in accordance with the terms of SAI Global Ltd's Licence 1108-c182 to Con-Serv Corporation Australia Pty. Ltd. All licensed copies of this document must be obtained from the Licensee. Standards Australia Ltd's material is not for resale, reproduction or distribution in whole or in part without written permission from SAI Global Ltd: tel +61 2 8206 6355 or copyright@saiglobal.com

1800 GRAB RAIL (R

(FREE 1800 472 272)

CON-SERV CORP. AUSTRALIA PTY. LTD.A. B. N. 97 010 372 639


17 Glentanna Street, Kedron Brisbane Qld 4031 Australia Telephone:+61 (0)7 3630 5744 Facsimile:+61 (0)7 3630 5755

Email: mail@con-serv.com.au Website: www.con-serv.com.au



BATHROOM ACCESSORIES - MODENA COLLECTION

A distinctive range of premium accessories.



BATHROOM ACCESSORIES - MODENA COLLECTION

A distinctive range of premium accessories.



	Code	Finish	Features
GLASS SHELF	BA 108 C BA 729 C BO	Chrome Spare part Barrier only	530mm x 10mm clear tempered glass shelf. Brackets chrome plated brass.
HAND TOWEL RAIL	BA 111 C	Chrome	280mm Ø to Ø wall fixings.
DAREN HALDED			Concealed wall mounts 310
PAPER HOLDER	BA 112 C	Chrome	Chrome plated brass.
			50 174
TOILET BRUSH WITH HOLDER	BA 114 C	Chrome	Brass made wall mounted toilet brush set with frosted glass
	BA 714 FR GO BA 714 WT BO BA 714 C BH	Spare parts Glass only Brush head only Handle only	bowl. 350 140
ROBE HOOK SINGLE	BA 115 C	Chrome	Chrome plated brass.
		Sillottic	52 52 52 Con-Serv Grab Rail Manual


N-SERV vise systems

	Code	Finish	Features
SOAP DISH HOLDER	BA 701 C	Chrome	Chrome plated brass.
TOWEL RING	BA 703 C	Chrome	Chrome plated brass.
TOWEL RAIL SINGLE 600mm	BA 704 C	Chrome	600mm Ø to Ø wall flange. 80 150
TOWEL RAIL SINGLE 800mm	BA 705 C	Chrome	800mm Ø to Ø wall flange. 800 800 150
TOWEL RAIL DOUBLE 600mm 4 Con-Serv Grab Rail Manual	BA 706 C	Chrome	600mm Ø to Ø wall flange.


ERV













BATHROOM BASKETS - COMFORT COLLECTION

Select from a range of various depths, rectangle, corner and semi-circular wire basket designs that display strength and creative excellence. Constructed of heavy chrome plated brass. All baskets have innovative concealed fixings.

BATHROOM RECTANGULAR BASKE	Code	Finish	Features
	BB 011 C	Chrome	67 300
RECTANGULAR BASKET LARGE	WB 001 C	Chrome	138 85.5
RECTANGULAR BASKET MEDIUM	WB 002 C	Chrome	128 65.5
OPEN FRONT RECTANGULAR BASK	WB 004 C	Chrome	128 37.5
OPEN FRONT RECTANGULAR BASK	WB 005 C	Chrome	103 37.5
BATHROOM CORNER BASKET	BB 017 C	Chrome	767 194 194
CORNER BASKET WITH HOOK CORNER BASKET MEDIUM	WB 006 C	Chrome	206
8 Con-Serv Grab Rail Manual	WB 008 C	Chrome	164 85.5



BATHROOM RAILS - COMFORT COLLECTION

All purpose 25mm rail for providing extra support and stability. Fabricated from brass tube with 50mm triple screw brass wall mount plates and screw on end caps. Stainless steel fixing screws supplied.

Comfort rails (25mm) do not comply with requirements of AS 1428.1-2009.

	Code	Finish	Features
COMFORT RAIL 300mm	CR 300 C	Chrome	300mm Ø to Ø wall fixings.
COMFORT RAIL 450mm	CR 450 C	Chrome	450mm Ø to Ø wall fixings.
COMFORT RAIL 600mm			
COMFORT RAIL 900mm	CR 600 C	Chrome	600mm Ø to Ø wall fixings.



Shower Systems for Healthcare Applications

Shower systems for healthcare applications usually require the installation of height adjustable handheld showers to cater for the able bodied as well as those who need to use a shower chair to clean themselves. There must also be provisions for assistance where someone is incapable of performing the cleaning task unaided. Handheld showers for these applications should be light weight, capable of withstanding dropping, easily held in soapy hands and have a soft spray pattern as to not irritate sensitive skin. Hoses should have a smooth surface to allow thorough cleaning as well. Con-Serv's Hosfab® handheld showers and hoses meet these requirements.

Where requested a handpiece that has an additional pulsating action to relax or to provide aqua-massage hydrotherapy treatment to relieve pain or promote healing can be supplied.

Handheld showers for professional use are supplied with licenced dual check valves to stop contamination of the water system. As with all Con-Serv handheld showers, the valves are located with the flow control at the wall outlet elbow.

Careful selection from the Hosfab® range will result in a shower support system that has been designed to fit many applications and give years of reliable service.



Select from our five ranges of Hosfab® shower systems for healthcare applications

PWD Independent Accessible Hosfab® Shower Kits11
Commercial Hosfab® Shower Options
Home Care Hosfab® Shower Selections 16 - 17
Premium Hosfab® Shower Selections
Premium Linear Hosfab® Shower Selections21















PWD INDEPENDENT ACCESSIBLE HOSFAB® -SHOWER KITS WITH PUSH-PULLME® FOR SEATED USERS

Independent accessible healthcare kits are made from the highest quality tested products and materials and feature dual check facilities as per AS/NZ 3500. The grab rails are fabricated from 304 stainless steel and assembled with 50mm chromed brass screw on Hygienic Seal® flange covers with Thermoplastic Elastomer (TPE) fitted seals and comply with clause 17 of

AS 1428.1-2009 for Design and Construction.

CON-SERV'S INTERCHANGE® SPIGOT GUARANTEES POSITIVE CONNECTIONS

AS 1428.1 - 2009 15.5.6 Shower Head

An adjustable shower head holder shall be provided to support the shower head and shall allow the graspable portion of the shower head to be positioned at various angles and heights and also allow the graspable portion of the shower head to be located at heights between 1000mm and 1800mm above the plane of the finished floor and allow access and adjustment from a seated position.

The above clause only applies to bathrooms specifically designed for People with Disabilities (PWD) in public buildings, factories, hotels, motels and designated PWD bathrooms in hospitals, homes for the elderly and nursing homes.

	Code	Finish	Features
PWD KIT 3			
	ID 01803 CW	Chrome/White 1.5m hose and handpiece	1000mm x 32mm Satin Supreme™ grab rail 50mm brass screw on Hygienic Seal® flange Solid brass Friction Slide cradle
	ID 01803 C	Chrome 1.5m hose and handpiece	 Push-PullMe® shower height adjustment rod White or Chrome ABS Hosfab® handpiece DR brass wall outlet elbow DR brass 9L/min Flow Interchange® Spigot
1000 350	ID 01803 CW2	Chrome/White 2m hose and handpiece	 Licenced dual check/non-return valve 57mm solid brass round flat flange Appropriate coloured 1.5m or 2m PVC hose
Brass Friction	ID 01803 C2	Chrome 2m hose	AS 1428.1
Slide Cradle with Push-PullMe®		and handpiece	HYGIENIC SEAL® PWD SHOWER COMPLIANT
PWD KIT 20	Please specify le	ft or right hand	
		Chrome/White 1.5m hose	• 700mm x 1100mm Satin Supreme™ grab rail
Brass Friction		and handpiece	Inverted "T" left or right handed 50mm brass screw on Hygienic Seal® flange
Slide Cradle with Push-PullMe®	ID 01820 CW LH	Left hand	Solid brass Friction Slide cradle
T Pusii-Fullivie	ID 01820 CW RH	Right hand	Push-PullMe® shower height adjustment rod
		Chrome 1.5m hose	White or Chrome ABS Hosfab® handpiece DR have a wall and lateral to the self-self-self-self-self-self-self-self-
1100 350		and handpiece	DR brass wall outlet elbow DR brass 9L/min Flow Interchange® Spigot
	ID 01820 C LH	Left hand	Licenced dual check/non-return valve
	ID 01820 C RH	Right hand	57mm solid brass round flat flange
\		Chrome/White 2m hose	Appropriate coloured 1.5m or 2m PVC hose
		and handpiece	
	ID 01820 CW2 LH	Left hand	
	ID 01820 CW2 RH	Right hand	AS 1428.1
Drawn LH 205 495		Chrome 2m hose	
(Left Hand) 700		and handpiece	
Drawn RH	ID 01820 C2 LH	Left hand	HYGIENIC SEAL® PWD SHOWER COMPLIANT
(Right Hand)	ID 01820 C2 RH	Right hand	HYGIENIC SEAL COMPLIANT
PWD KIT 21	Please specify le	ft or right hand	
		Chrome/White 1.5m hose	1170mm x 1100mm Satin Supreme™ grab rail
		and handpiece	Inverted "T" left or right handed 50mm brass screw on Hygienic Seal® flange
16 of 16	ID 01821 CW LH	Left hand	Solid brass Friction Slide cradle
T T T T T T T T T T	ID 01821 CW RH	Right hand	Push-PullMe® shower height adjustment rod
Drawn RH		Chrome 1.5m hose	White or Chrome ABS Hosfab® handpiece DR brass wall outlet elbow
1100 350 (Right Hand)		and handpiece	DR brass wall outlet elbow DR brass 9L/min Flow Interchange® Spigot
	ID 01821 C LH	Left hand	Licenced dual check/non-return valve
_ • c	ID 01821 C RH	Right hand	• 57mm solid brass round flat flange
		Chrome/White 2m hose	Appropriate coloured 1.5m or 2m PVC hose
		and handpiece	
990	ID 01821 CW2 LH	Left hand	
1170 Drawn LH	ID 01821 CW2 RH	Right hand	
(Left Hand)		Chrome 2m hose	AS 1428.1
WATER RATING www.waterrating.gov.au		and handpiece	
9 litres per Brass Friction	ID 01821 C2 LH	Left hand	(2)
WaterMark Licence No. 0046 ASINZS 3662 ASINZS 3662 ASINZS 3662 ASINZS 3662	ID 01821 C2 RH	Right hand	HYGIENIC SEAL® PWD SHOWER COMPLIANT



COMMERCIAL HOSFAB® SHOWER - OPTIONS



	Code	Finish	Faatuusa	VaterMark AS/NZS 3662 WMKT 21147	5
COMMERCIAL KIT 1	HS 01801 CW HS 01801 C HS 01801 CW2 HS 01801 C2	White 1.5m hose and handpiece Chrome 1.5m hose and handpiece White 2m hose and handpiece Chrome 2m hose and hand piece	White or Chrome ABS Hosfab® handpiece White or Chrome PVC 1.5m or 2m hose 85mm DR brass right angled wall outlet elbo DR brass 9L/min Flow Interchange® Spigot Licenced dual check/non-return valve 57mm solid brass round flat flange	WC	
			3 Star - 9L/min rated as per WELS licence nur	mber 0046.	
COMMERCIAL KIT 6	HS 01806 CW HS 01806 C HS 01806 CW2 HS 01806 C2	White 1.5m hose and handpiece Chrome 1.5m hose and handpiece White 2m hose and handpiece Chrome 2m hose and handpiece	White or Chrome ABS Hosfab® handpiece White or Chrome PVC 1.5m or 2m hose DR brass wall outlet elbow DR brass 9L/min Flow Interchange® Spigot Licenced dual check/non-return valve 57mm solid brass round flat flange ABS grab rail Glide Slide cradle ABS Glide Slide Cradle 3 Star - 9L/min rated as per WELS licence nur	mber 0046	
COMMERCIAL KIT 12			No grab rail supplied.		
SOMWENDIAL KIT 12	HS 01812 CW HS 01812 C HS 01812 CW2 HS 01812 C2	White 1.5m hose and handpiece Chrome 1.5m hose and handpiece White 2m hose and handpiece Chrome 2m hose and handpiece	White or Chrome ABS Hosfab® handpiece White or Chrome PVC 1.5m or 2m hose DR brass wall outlet elbow DR brass 9L/min Flow Interchange® Spigot 57mm solid brass round flat flange		
			3 Star - 9L/min rated as per WELS licence nu Handheld shower kit for all grab rail model		



AS/NZS 3662 WMKT 21147

COMMERCIAL HOSFAB® SHOWER - OPTIONS

Commercial healthcare shower support options, made from the highest quality tested products and materials and feature dual check facilities as per AS/NZ 3500. Designed for installations in hospitals, homes for the elderly, nursing homes, private and public facilities. Grab rail kits comply with clause 17 of 1428.1-2009 for Design and Construction.




	Code	Finish	Features
COMMERCIAL KIT 3	HS 01803 CW	Chrome/White 1.5m hose and handpiece	 900mm x 32mm Satin Supreme™ grab rail 50mm brass screw on Hygienic Seal® flange Solid brass Friction Slide cradle White or Chrome ABS Hosfab® handpiece
	HS 01803 C	Chrome 1.5m hose and handpiece	 White or Chrome 1.5m or 2m hose DR brass wall outlet elbow DR brass 9L/min Flow Interchange® Spigot Licenced dual check/non-return valve
4	HS 01803 CW2	Chrome/White 2m hose and handpiece	57mm Solid brass round flat flange Brass Friction Slide Cradle
	HS 01803 C2	Chrome 2m hose and handpiece	
COMMERCIAL KIT 9			AS 1428.1 HYGIENIC SEAL® DIMENSIONAL COMPLIANT
GOWIWERGIAL KIT 9	HS 01809 CW	Chrome/White 1.5m hose	 900mm x 32mm Satin Supreme™ grab rail 50mm brass screw on Hygienic Seal® flange
~		and handpiece	White or Grey/Chrome ABS Glide Slide cradle White or Chrome ABS Hosfab® handpiece
	HS 01809 C	Chrome 1.5m hose and handpiece	 White or Chrome 1.5m or 2m hose DR brass wall outlet elbow DR brass 9L/min Flow Interchange® Spigot Licenced dual check/non-return valve
1	HS 01809 CW2	Chrome/White 2m hose and handpiece	57mm Solid brass round flat flange ABS Glide
	HS 01809 C2	Chrome 2m hose and handpiece	Slide Cradle
			AS 1428.1 DIMENSIONAL COMPLIANT
O	GRAB RAIL SOAP DIS		Fastens to 32mm grap rail
The manager of the state of the	SD 032 GYC	Grey/Chrome	 Fastens to 32mm grab rail ABS construction Simple to clean
9 litres per minute Transfer and ANDES 448 License No. 0646 ASINZS 3662			



COMMERCIAL HOSFAB® SHOWER - OPTIONS

Commercial healthcare shower support options, made from the highest quality tested products and materials and feature dual check facilities as per AS/NZ 3500. Designed for installations in hospitals, homes for the elderly, nursing homes, private and public facilities. Grab rail kits comply with clause 17 of 1428.1-2009 for Design and Construction.





COMMERCIAL HOSFAB® SHOWER - OPTIONS

Commercial healthcare shower support options, made from the highest quality tested products and materials and feature dual check facilities as per AS/NZ 3500. Designed for installations in hospitals, homes for the elderly, nursing homes, private and public facilities. Grab rail kits comply with clause 17 of 1428.1-2009 for Design and Construction.

CON-SERV'S INTERCHANGE® SPIGOT GUARANTEES POSITIVE CONNECTIONS



	Code	Finish	Features
COMMERCIAL KIT 16	Please specify left	or right or middle fix	
1		Chrome/White 1.5m hose and handpiece	700mm x 1100mm Satin Supreme™ grab rail
100	MS 01816 CW LH	Left Hand	• 50mm brass screw on Hygienice Seal® flange
11 11	HS 01816 CW MF	Middle Fix	White or Grey/Chrome ABS Glide Slide cradle White or Chrome ABS Heafah® bandaises
TI TI	HS 01816 CW RH	Right Hand	White or Chrome ABS Hosfab® handpiece White or Chrome 1.5m or 2m hose
9	TIS OTOTO CW NIT	night Haliu	DR brass wall outlet elbow
		Chrome 1.5m hose and handpiece	DR brass 9L/min Flow Interchange® Spigot Licenced dual check/non-return valve 57mm solid brass round flat flange
	HS 01816 C LH	Left Hand	
	HS 01816 C MF	Middle Fix	ABS Glide
	HS 01816 C RH	Right Hand	Slide Cradle
Drawn LH (Left Hand) Drawn RH (Right	Hand)		
1		Chrome/White 2m hose and handpiece	Left and right hand models only comply with AS 1428.1-2009 for a 2 walled
P	HS 01816 CW2 LH	Left Hand	shower enclosure.
44	HS 01816 CW2 MF	Middle Fix	
	HS 01816 CW2 RH	Right Hand	
11 7	110 01010 GWZ 1111	riight Halia	
		Chrome 2m hose and handpiece	
I\ 1	110 04 04 0 00 1 11	1 - 0 11 1	AS 1428.1
1\/_	HS 01816 C2 LH	Left Hand	
C.	HS 01816 C2 MF	Middle Fix	(D)
	HS 01816 C2 RH	Right Hand	DIMENSIONAL
Drawn MF (Middle Fix)	113 01010 02 1111	Hight Hand	HYGIENIC SEAL® COMPLIANT
Drawn MF (Middle Fix) COMMERCIAL KIT 20		or right or middle fix	HYGIENIC SEAL® COMPLIANT
			• 700mm x 1100mm Satin Supreme™
		or right or middle fix	700mm x 1100mm Satin Supreme™ grab rail
		or right or middle fix	700mm x 1100mm Satin Supreme™ grab rail 50mm brass screw on Hygienice Seal® flange
	Please specify left	or right or middle fix Chrome/White 1.5m hose and handpiece	700mm x 1100mm Satin Supreme™ grab rail
	Please specify left HS 01820 CW LH	or right or middle fix Chrome/White 1.5m hose and handpiece Left Hand	700mm x 1100mm Satin Supreme [™] grab rail 50mm brass screw on Hygienice Seal® flange Solid brass Friction Slide cradle
	Please specify left HS 01820 CW LH HS 01820 CW MF	or right or middle fix Chrome/White 1.5m hose and handpiece Left Hand Middle Fix	700mm x 1100mm Satin Supreme [™] grab rail 50mm brass screw on Hygienice Seal® flange Solid brass Friction Slide cradle White or Chrome ABS Hosfab® handpiece White or Chrome 1.5m or 2m hose DR brass wall outlet elbow
	Please specify left HS 01820 CW LH HS 01820 CW MF	or right or middle fix Chrome/White 1.5m hose and handpiece Left Hand Middle Fix	700mm x 1100mm Satin Supreme [™] grab rail 50mm brass screw on Hygienice Seal® flange Solid brass Friction Slide cradle White or Chrome ABS Hosfab® handpiece White or Chrome 1.5m or 2m hose DR brass wall outlet elbow DR brass 9L/min Flow Interchange® Spigot
	Please specify left HS 01820 CW LH HS 01820 CW MF	or right or middle fix Chrome/White 1.5m hose and handpiece Left Hand Middle Fix Right Hand	700mm x 1100mm Satin Supreme [™] grab rail 50mm brass screw on Hygienice Seal® flange Solid brass Friction Slide cradle White or Chrome ABS Hosfab® handpiece White or Chrome 1.5m or 2m hose DR brass wall outlet elbow
	Please specify left HS 01820 CW LH HS 01820 CW MF	or right or middle fix Chrome/White 1.5m hose and handpiece Left Hand Middle Fix Right Hand	• 700mm x 1100mm Satin Supreme™ grab rail • 50mm brass screw on Hygienice Seal® flange • Solid brass Friction Slide cradle • White or Chrome ABS Hosfab® handpiece • White or Chrome 1.5m or 2m hose • DR brass wall outlet elbow • DR brass 9L/min Flow Interchange® Spigot • Licenced dual check/non-return valve
	Please specify left HS 01820 CW LH HS 01820 CW MF HS 01820 CW RH	or right or middle fix Chrome/White 1.5m hose and handpiece Left Hand Middle Fix Right Hand Chrome 1.5m hose and handpiece	700mm x 1100mm Satin Supreme™ grab rail 50mm brass screw on Hygienice Seal® flange Solid brass Friction Slide cradle White or Chrome ABS Hosfab® handpiece White or Chrome 1.5m or 2m hose DR brass wall outlet elbow DR brass 9L/min Flow Interchange® Spigot Licenced dual check/non-return valve 57mm solid brass round flat flange
	HS 01820 CW LH HS 01820 CW RH HS 01820 CW RH HS 01820 C LH HS 01820 C LH	or right or middle fix Chrome/White 1.5m hose and handpiece Left Hand Middle Fix Right Hand Chrome 1.5m hose and handpiece Left Hand	• 700mm x 1100mm Satin Supreme™ grab rail • 50mm brass screw on Hygienice Seal® flange • Solid brass Friction Slide cradle • White or Chrome ABS Hosfab® handpiece • White or Chrome 1.5m or 2m hose • DR brass wall outlet elbow • DR brass 9L/min Flow Interchange® Spigot • Licenced dual check/non-return valve
COMMERCIAL KIT 20	HS 01820 CW LH HS 01820 CW RH HS 01820 CW RH HS 01820 C LH HS 01820 C LH	or right or middle fix Chrome/White 1.5m hose and handpiece Left Hand Middle Fix Right Hand Chrome 1.5m hose and handpiece Left Hand Middle Fix Right Hand	• 700mm x 1100mm Satin Supreme™ grab rail • 50mm brass screw on Hygienice Seal® flange • Solid brass Friction Slide cradle • White or Chrome ABS Hosfab® handpiece • White or Chrome 1.5m or 2m hose • DR brass wall outlet elbow • DR brass 9L/min Flow Interchange® Spigot • Licenced dual check/non-return valve • 57mm solid brass round flat flange Brass Friction Slide Cradle
COMMERCIAL KIT 20	HS 01820 CW LH HS 01820 CW RH HS 01820 CW RH HS 01820 C LH HS 01820 C LH	or right or middle fix Chrome/White 1.5m hose and handpiece Left Hand Middle Fix Right Hand Chrome 1.5m hose and handpiece Left Hand Middle Fix	• 700mm x 1100mm Satin Supreme™ grab rail • 50mm brass screw on Hygienice Seal® flange • Solid brass Friction Slide cradle • White or Chrome ABS Hosfab® handpiece • White or Chrome 1.5m or 2m hose • DR brass wall outlet elbow • DR brass 9L/min Flow Interchange® Spigot • Licenced dual check/non-return valve • 57mm solid brass round flat flange Brass Friction Slide Cradle Left and right hand models only comply
COMMERCIAL KIT 20	HS 01820 CW LH HS 01820 CW MF HS 01820 CW RH HS 01820 C LH HS 01820 C LH HS 01820 C RF Hand)	or right or middle fix Chrome/White 1.5m hose and handpiece Left Hand Middle Fix Right Hand Chrome 1.5m hose and handpiece Left Hand Middle Fix Right Hand Chrome/White 2m hose and handpiece	• 700mm x 1100mm Satin Supreme™ grab rail • 50mm brass screw on Hygienice Seal® flange • Solid brass Friction Slide cradle • White or Chrome ABS Hosfab® handpiece • White or Chrome 1.5m or 2m hose • DR brass wall outlet elbow • DR brass 9L/min Flow Interchange® Spigot • Licenced dual check/non-return valve • 57mm solid brass round flat flange Brass Friction Slide Cradle
COMMERCIAL KIT 20	HS 01820 CW LH HS 01820 CW RH HS 01820 CW RH HS 01820 C LH HS 01820 C MF HS 01820 C RH HS 01820 C RH	or right or middle fix Chrome/White 1.5m hose and handpiece Left Hand Middle Fix Right Hand Chrome 1.5m hose and handpiece Left Hand Middle Fix Right Hand Chrome/White 2m hose and handpiece Left Hand	• 700mm x 1100mm Satin Supreme™ grab rail • 50mm brass screw on Hygienice Seal® flange • Solid brass Friction Slide cradle • White or Chrome ABS Hosfab® handpiece • White or Chrome 1.5m or 2m hose • DR brass wall outlet elbow • DR brass 9L/min Flow Interchange® Spigot • Licenced dual check/non-return valve • 57mm solid brass round flat flange Brass Friction Slide Cradle Left and right hand models only comply with AS 1428.1-2009 for a 2 walled
COMMERCIAL KIT 20	HS 01820 CW LH HS 01820 CW RH HS 01820 CW RH HS 01820 C LH HS 01820 C MF HS 01820 C RH HS 01820 C RH	or right or middle fix Chrome/White 1.5m hose and handpiece Left Hand Middle Fix Right Hand Chrome 1.5m hose and handpiece Left Hand Middle Fix Right Hand Chrome/White 2m hose and handpiece Left Hand Middle Fix Right Hand	• 700mm x 1100mm Satin Supreme™ grab rail • 50mm brass screw on Hygienice Seal® flange • Solid brass Friction Slide cradle • White or Chrome ABS Hosfab® handpiece • White or Chrome 1.5m or 2m hose • DR brass wall outlet elbow • DR brass 9L/min Flow Interchange® Spigot • Licenced dual check/non-return valve • 57mm solid brass round flat flange Brass Friction Slide Cradle Left and right hand models only comply with AS 1428.1-2009 for a 2 walled
COMMERCIAL KIT 20	HS 01820 CW LH HS 01820 CW RH HS 01820 CW RH HS 01820 C LH HS 01820 C MF HS 01820 C RH HS 01820 C RH	or right or middle fix Chrome/White 1.5m hose and handpiece Left Hand Middle Fix Right Hand Chrome 1.5m hose and handpiece Left Hand Middle Fix Right Hand Chrome/White 2m hose and handpiece Left Hand	• 700mm x 1100mm Satin Supreme™ grab rail • 50mm brass screw on Hygienice Seal® flange • Solid brass Friction Slide cradle • White or Chrome ABS Hosfab® handpiece • White or Chrome 1.5m or 2m hose • DR brass wall outlet elbow • DR brass 9L/min Flow Interchange® Spigot • Licenced dual check/non-return valve • 57mm solid brass round flat flange Brass Friction Slide Cradle Left and right hand models only comply with AS 1428.1-2009 for a 2 walled
COMMERCIAL KIT 20	HS 01820 CW LH HS 01820 CW RH HS 01820 CW RH HS 01820 C LH HS 01820 C MF HS 01820 C RH HS 01820 C RH	or right or middle fix Chrome/White 1.5m hose and handpiece Left Hand Middle Fix Right Hand Chrome 1.5m hose and handpiece Left Hand Middle Fix Right Hand Chrome/White 2m hose and handpiece Left Hand Middle Fix Right Hand Middle Fix Right Hand	• 700mm x 1100mm Satin Supreme™ grab rail • 50mm brass screw on Hygienice Seal® flange • Solid brass Friction Slide cradle • White or Chrome ABS Hosfab® handpiece • White or Chrome 1.5m or 2m hose • DR brass wall outlet elbow • DR brass 9L/min Flow Interchange® Spigot • Licenced dual check/non-return valve • 57mm solid brass round flat flange Brass Friction Slide Cradle Left and right hand models only comply with AS 1428.1-2009 for a 2 walled
COMMERCIAL KIT 20	HS 01820 CW LH HS 01820 CW RH HS 01820 CW RH HS 01820 C LH HS 01820 C MF HS 01820 C RH HS 01820 C RH	or right or middle fix Chrome/White 1.5m hose and handpiece Left Hand Middle Fix Right Hand Chrome 1.5m hose and handpiece Left Hand Middle Fix Right Hand Chrome/White 2m hose and handpiece Left Hand Middle Fix Right Hand	• 700mm x 1100mm Satin Supreme™ grab rail • 50mm brass screw on Hygienice Seal® flange • Solid brass Friction Slide cradle • White or Chrome ABS Hosfab® handpiece • White or Chrome 1.5m or 2m hose • DR brass wall outlet elbow • DR brass 9L/min Flow Interchange® Spigot • Licenced dual check/non-return valve • 57mm solid brass round flat flange Brass Friction Slide Cradle Left and right hand models only comply with AS 1428.1-2009 for a 2 walled shower enclosure.
COMMERCIAL KIT 20	HS 01820 CW LH HS 01820 CW RH HS 01820 CW RH HS 01820 C LH HS 01820 C MF HS 01820 C RH HS 01820 C RH	or right or middle fix Chrome/White 1.5m hose and handpiece Left Hand Middle Fix Right Hand Chrome 1.5m hose and handpiece Left Hand Middle Fix Right Hand Chrome/White 2m hose and handpiece Left Hand Middle Fix Right Hand Middle Fix Right Hand	• 700mm x 1100mm Satin Supreme™ grab rail • 50mm brass screw on Hygienice Seal® flange • Solid brass Friction Slide cradle • White or Chrome ABS Hosfab® handpiece • White or Chrome 1.5m or 2m hose • DR brass wall outlet elbow • DR brass 9L/min Flow Interchange® Spigot • Licenced dual check/non-return valve • 57mm solid brass round flat flange Brass Friction Slide Cradle Left and right hand models only comply with AS 1428.1-2009 for a 2 walled





Drawn MF (Middle Fix)

GRAB RAIL SOAP DISH HOLDER

Middle Fix

Right Hand

HS 01820 C2 MF

HS 01820 C2 RH

SD 032 GYC Grey/Chrome



- Fastens to 32mm grab rail
- ABS construction
- Simple to clean

HYGIENIC SEAL®



HOME CARE HOSFAB® - SHOWER SELECTIONS WITH 900mm GRAB RAIL AND ABS GLIDE SLIDE CRADLE

- 900mm Polish Supreme[™] grab rail
- 50mm brass screw on Hygienic Seal® flange
- White or Grey/Chrome ABS Glide Slide
- White or Chrome ABS handiece
- White or Chrome 1.5m hoseDR brass wall outlet elbow
- DR brass 9L/min Flow Interchange® Spigot
- Licenced dual check/non-return valve
- 57mm solid brass round flat flange



CON-SERV'S INTERCHANGE® SPIGOT GUARANTEES POSITIVE CONNECTIONS



Model shown: GS 900X C




Model shown: GS 071P C MF

HOME CARE HOSFAB® - SHOWER SELECTIONS WITH 700 x 1100mm GRAB RAIL AND ABS GLIDE SLIDE CRADLE

- 700mm x 1100mm Polish Supreme[™] grab rail
- 50mm brass Hygienic Seal® flange
- White or Grey/Chrome ABS Glide Slide
- White or Chrome ABS handpiece
- White or Chrome 1.5m hose
- DR brass wall outlet elbow
- DR brass 9L/min Flow Interchange® Spigot
- Licenced dual check/non-return valve
- 57mm solid brass round flat flange







PREMIUM HOSFAB® - SHOWER SELECTIONS WITH 900mm GRAB RAIL/FRICTION SLIDE TRACK & CRADLE

Finish

- ullet 900mm Polish Supreme $^{\mathrm{TM}}$ grab rail
- 50mm brass Hygienic Seal® flange
- Solid brass Friction Slide Track
- Solid brass Friction Slide Cradle

Model


- ABS grab rail Soap Dish
- Appropriate coloured 1.5m PVC hose

Code

- DR brass wall outlet elbow
- DR brass 9L/min Flow Interchange® Spigot
- Licenced dual check/non-return valve
- 57mm solid brass round flat flange

Features







PREMIUM HOSFAB® - SHOWER SELECTIONS WITH 700 x 1100mm GRAB RAIL/FRICTION SLIDE TRACK & CRADLE


- 700mm x 1100mm Polish Supreme™
- 50mm brass Hygienic Seal® flange
- Solid brass Friction Slide Track
- Solid brass Friction Slide Cradle

Model shown: GB 071P C MF

· ABS grab rail Soap Dish

- Appropriate coloured 1.5m PVC hose
- DR brass wall outlet elbow
- DR brass 9L/min Flow Interchange® Spigot
- · Licenced dual check/non-return valve
- 57mm solid brass round flat flange







PREMIUM HOSFAB® - SHOWER SELECTIONS WITH 760 x 1000 x 1100mm GRAB RAIL/FRICTION SLIDE TRACK & CRADLE

- 760mm x 1000mm x 1100mm Polish Supreme[™]
- 50mm brass Hygienic Seal® flange
- Solid brass Friction Slide Track
- Solid brass Friction Slide Cradle
- ABS grab rail Soap Dish

CON-SERV'S INTERCHANGE® SPIGOT GUARANTEES POSITIVE CONNECTIONS

- Appropriate coloured 1.5m PVC hose
- DR brass wall outlet elbow
- DR brass 9L/min Flow Interchange® Spigot
- · Licenced dual check/non-return valve
- 57mm solid brass round flat flange



Model Code Finish Features STREAMJET™ XL TURBO PULSATOR GB 711S C LH Chrome Premium 130mm ABS multi-function Please specify left or right hand handpiece with concentric jet spray **GB 711S C RH** Chrome adjustable through soft zones to turbo massage action for hydrotherapy treatment. GB 711Z C LH Stylish arched shape ABS handpiece, Chrome adjustable from firm spray through soft **GB 711Z C RH** Chrome zones to pulsate-massage. Drawn LH (Left Hand) Ø50 **PRINCESS GB 711P C LH** Chrome Arched shape performance ABS handpiece Ø31.80 with wide single pattern low impact spray GB 711P C RH Chrome and exfoliating rub-clean spray diffuser. **Other Colours Available** 8 dual check 1.5m hose **STREAMJET™** GB 711J C LH Chrome Premium 100mm ABS chrome faced ABS handpiece, with concentric jet spray diffusor, GB 711J C RH Chrome giving a full pattern band of spray circles. A GB 711J WTC LH White/Chrome most effective dense shower. Drawn RH (Right Hand) GB 711J WTC RH White/Chrome ₩ Ø50 031.80 - Ø57 STREAMJET™ XL dual check **GB 711X C LH** Chrome Premium extra large (XL) 130mm ABS 1100 chrome faced handpiece with concentric jet GB 711X CRH Chrome spray diffusor producing a rain-like soothing and relaxing shower. STREAMJET™ TURBO PULSATOR Drawn LH (Left Hand) **GB 711T C LH** Chrome Premium 100mm ABS multi-function handpiece with concentric jet spray GB 711T C RH Chrome adjustable through soft zones to turbo massage action for hydrotherapy treatment. WaterMark

Model shown: GB 711P C LH



PREMIUM LINEAR HOSFAB® - SHOWER SELECTIONS WITH 900mm GRAB RAIL AND BRASS FRICTION SLIDE CRADLE

- 900mm Polish Supreme[™] grab rail
- 50mm brass "T" leg Linear flange
- 32mm brass Friction Slide Cradle
- Chrome Silverflex[™] 1.5m PVC hose
- DR brass wall outlet elbow
- DR brass 9L/min Interchange® Spigot
- Licenced dual check/non-return valve
- 57mm brass round flat flange
- 32mm grab rail soap dish







ABOUT STAINLESS STEEL GRAB RAILS

ALLOY TYPES

304 is the basic chromium-nickel austenitic stainless steel and has been found suitable for a wide range of applications. It is the most readily available in a variety of product forms. This grade is easy to form and fabricate and is resistant to corrosion.

304L is the low carbon version of 304. The use of the letter "L" after the grade number means that the carbon content is restricted to a maximum of 0.03% (normal levels are 0.08%). The lower level of carbon is usually used where welding is performed and helps to prevent the chromium from being depleted so it can form the "passive" oxide layer, giving excellent resistance to corrosion and metallurgically incapable of rusting.

316 offers more corrosion-resistance through the addition of molybdenum, this grade is desirable where the possibility of severe corrosion exists, such as marine environments.

316L is the low carbon version of 316.

WHAT DOES 18/8MEAN

The first number is the amount of chromium that is contained in the stainless. The second number is the amount of nickel. So 18/8 means that this stainless steel contains 18% chromium and 8% nickel and is part of the grade family "300 series" stainless which is non-magnetic.

CARE OF STAINLESS STEEL

To have an optimum corrosion resistant stainless steel, surfaces must be clean and have an adequate supply of oxygen to maintain their 'passive' surface layer. Passive Film is invisible in stainless steel. It's created when oxygen combines with chromium in the stainless to form chromium oxide.

Stainless steel supplied by reputable manufacturers or fabricators will normally be clean and contamination free. Generally, stubborn stains and discolouration corrosion occurs when there is an overall breakdown of the 'passive' film, due to incorrect cleaning procedures. Rust staining can occur as anything from a slight brown 'bloom' on the surface to severe surface pitting or rusty scour marks on items such as GRAB RAILS and HAND RAILS. Cleanliness and stainless steel are closely related in many applications and each is dependent upon the other. Cleanliness is essential for maximum resistance to corrosion.

THE CLEANING OF STAINLESS STEEL

Alkali cleaners such as baking soda or ammonia are effective to clean stainless steel. Always attempt the mildest cleaning method first. Stainless steel's best friends are quite simply soap, mild detergent or ammonia solution in warm water applied with a soft cloth or nylon sponge for polished finishes followed by a clean water rinse. Dry wipe eliminates the possibility of water stains. Occasionally, the use of the least coarse nylon scouring pad may be required for satin finishes.

WHAT TO AVOID

Do not use ordinary steel wool. Iron particles can become embedded in stainless steel and cause 'iron' contamination.

Do not use chlorides or acids as they are reactive to stainless steel. Strong acid solutions like hydrochloric acid or "spirit of salts" are sometimes used to clean masonry and tiling of new bathrooms and toilets, but they should NEVER be permitted to come into contact with metals. INCLUDING STAINLESS STEEL.

Halogen salts, especially chlorides easily penetrate the "passive film" of stainless steel and will allow corrosive attack to occur.

The halogens are easy to recognize because they end in the letters "INE". Listed in order of their activity are:

- Fluorine
- Chlorine
- Bromine
- lodine
- Astatine

Never use brick cleaning liquids which contain hydrochloric acid. Many cleaning solutions and solvents contain chlorinated hydrocarbons. If a cleaner containing chlorides, bleaches and hypochlorites are used, it must be promptly and thoroughly cleaned off.

Please note: The Con-Serv® warranty on grab rails will be null and void should they be exposed to chemical corrosion due to incompetent cleaning practices.

The Con-Serv® Hygienic Seal® flange cover has a 5° radius to comply with AS 1428.1-2009.

Be most cautious of claims made by imitators.









Regular grab rail with 78mm Clam Flange®, domed cover, for the concealing of screw fixing points of the grab rail mount flange. The Clam Flange® snaps over notch lugs on the mount flange locking it firmly in place.

Con-Serv[®] Clam Flange[®] grab rails are fabricated from 32mm x 1.2mm grade 304, 18/8 stainless steel, and pre-formed 76mm 5 screw wall mount plate with 360mm rear weld joint. Assembled with 78mm domed Clam Flange[®] cover with 5° radius to comply with clause 17 of AS 1428.1-2009 for Design and Construction and available in the following finishes: Satin Supreme[™], Polish Supreme[™], Diamond Shur-Grip[®] and UV Light stabilised colour.


Grab Rail Specifications

Outside Diameter




Grab rails should not be less than 30mm and not more than 40mm outside diameter, or they shall have sectional shape within the limits of 30mm and 40mm diameter.

Wall Clearance



Unless otherwise specified, the clearance between grab rail and the adjacent wall surface or other obstruction shall not be less than 50mm and not more than 60mm. This clearance shall extend above the top of the grab rail by not less than 600mm.


Mounting Height



All horizontal fixings to be underslung brackets as per standard requirements.

Con-Serv® grab rail underslung bracket is 56mm below rail.


Minimum Obstruction




Grab rails shall be fixed so that there is no obstruction to the hand along the top 270° of the rail.

Installation Instructions for Grab Rail with Clam Flange®

Grab rails with Clam Flange® must be fitted to a solid wall or other firm surface and installed by qualified trades people. Con-Serv® grab rails will support loads in excess of 113kg when correctly installed, complying with accessibility guidelines of AS 1428.1-2009.



Fixing to brickwork, blockwork or concrete use stainless steel 50mm x 14g self tapping screws.



Fixing to timber use stainless steel 50mm x 14g self tapping screws.

Custom Made Grab Rail Measurement Instructions

- 1. Measure all bends to the centre line.
- 2. When designing any grab rail, all measurements are centre to centre of the rail.
- 3. Dimensions should be clearly shown between rail centres or to wall corners.
- 4. For handed grab rails nominate left or right hand e.g. Toilet assist rails are sitting on the pan, not looking at it.





CLAM FLANGE® - STRAIGHT GRAB RAILS

Clam Flange® regular 32mm grab rail, fabricated from 304 stainless steel with 78mm pre-formed domed Clam Flange®. Manufactured to comply with clause 17 of AS 1428.1-2009 for Design and Construction. For horizontal fixing of grab rails, mount 800mm to 810mm above floor level.

	0.1	E	į.
300mm	Code	Finish	Features
\$55 300	CF 300 SS CF 300 PS CF 300 DS CF 300 WT	Satin Supreme™ Polish Supreme™ Diamond Shur-Grip® White	300mm Ø to Ø Stainless steel fixing screws supplied. Other Colours Available CLAM FLANGE®
400mm	CF 400 SS CF 400 PS CF 400 DS CF 400 WT	Satin Supreme [™] Polish Supreme [™] Diamond Shur-Grip® White	400mm Ø to Ø Stainless steel fixing screws supplied. Other Colours Available CLAM FLANGE®
450mm	CF 450 SS CF 450 PS CF 450 DS CF 450 WT	Satin Supreme [™] Polish Supreme [™] Diamond Shur-Grip® White	450mm Ø to Ø Stainless steel fixing screws supplied. Other Colours Available CLAM FLANGE®
500mm 600mm	CF 500 SS CF 500 PS CF 500 DS CF 500 WT	Satin Supreme [™] Polish Supreme [™] Diamond Shur-Grip® White	500mm Ø to Ø Stainless steel fixing screws supplied. Other Colours Available CLAM FLANGE®
700mm	CF 600 SS CF 600 PS CF 600 DS CF 600 WT	Satin Supreme [™] Polish Supreme [™] Diamond Shur-Grip® White	600mm Ø to Ø Stainless steel fixing screws supplied. Other Colours Available CLAM FLANGE®
555 700	CF 700 SS CF 700 PS CF 700 DS CF 700 WT	Satin Supreme [™] Polish Supreme [™] Diamond Shur-Grip [®] White	700mm Ø to Ø Stainless steel fixing screws supplied. Other Colours Available CLAM FLANGE®
850mm x 800mm - FREE STANDING GRAB RAIL	CF 858 SS CF 858 PS	Satin Supreme [™] Polish Supreme [™]	850mm x 805mm free standing grab rail. Fabricated from 304 stainless steel and assembled with 78mm pre-formed domed Clam Flange®. Stainless steel fixing screws supplied.
No leg			CLAM FLANGE



CLAM FLANGE® - STRAIGHT GRAB RAILS

Clam Flange® regular 32mm grab rail, fabricated from 304 stainless steel with 78mm pre-formed domed Clam Flange®. Manufactured to comply with clause 17 of AS 1428.1-2009 for Design and Construction. For horizontal fixing of grab rails, mount 800mm to 810mm above floor level.

			Ę
	Code	Finish	Features
750mm			
	CF 750 SS CF 750 PS	Satin Supreme™ Polish Supreme™	750mm Ø to Ø Stainless steel fixing screws supplied. Other Colours Available
\$5	CF 750 DS	Diamond Shur-Grip®	
	CF 750 WT	White	
			CLAM FLANGE®
800mm			
	CF 800 SS	Satin Supreme™	800mm Ø to Ø
	CF 800 PS	Polish Supreme™	Stainless steel fixing screws supplied. Other Colours Available
55	CF 800 DS	Diamond Shur-Grip®	Construction of the state of th
	CF 800 WT	White	
			(CLAM FLANGE®)
900mm			
	CF 900 SS	Satin Supreme™	900mm Ø to Ø
	CF 900 PS	Polish Supreme™	Stainless steel fixing screws supplied. Other Colours Available
900	CF 900 DS	Diamond Shur-Grip®	Other Colours Available
55	CF 900 WT	White	
			(CLAM FLANGE®)
1000mm			
	CF 1000 SS	Satin Supreme™	1000mm Ø to Ø
	CF 1000 PS	Polish Supreme™	Stainless steel fixing screws supplied.
1000	CF 1000 DS	Diamond Shur-Grip®	Other Colours Available
1000	CF 1000 WT	White	
	01 1000 W1	Willito	
			(CLAM FLANGE®)
1100mm			(C. W. 1. D. W.C.)
	CF 1100 SS	Satin Supreme™	1100mm Ø to Ø
<u>→</u>	CF 1100 PS	Polish Supreme™	Stainless steel fixing screws supplied.
1100	CF 1100 DS	Diamond Shur-Grip®	Other Colours Available
555	CF 1100 WT	White	
	01 1100 W1	Willie	
			(CLAM FLANGE®)
1200mm			OD WITTE WILL
	CF 1200 SS	Satin Supreme™	1200mm Ø to Ø
_	CF 1200 PS	Polish Supreme™	Stainless steel fixing screws supplied.
1200	CF 1200 DS	Diamond Shur-Grip®	Other Colours Available
555	CF 1200 D3	White	
	01 1200 W1	Willio	
			(CLAM FLANGE®)
850mm x 800mm FREE STANDING GRAB RAIL	WITH ROTATING SL	JPPORT LEG	
850	CF 882 SS	Satin Supreme™	850mm x 805mm free standing grab rail with
	CF 882 PS	Polish Supreme [™]	rotating support leg. Fabricated from 304 stainless
ρ	01 002 10	i onon oupromo	steel and assembled with 78mm pre-formed domed Clam Flange®.
			Stainless steel fixing screws supplied.
805			
d⊤			
			OLAM FLAMOF®
150			CLAM FLANGE®

CLAM FLANGE® - AMBULANT & TOILET GRAB RAILS

Clam Flange® regular 32mm grab rail, fabricated from 304 stainless steel with 78mm pre-formed domed Clam Flange®. Manufactured to comply wtith clause 17 of AS 1428.1-2009 for Design and Construction. For horizontal fixing of grab rails, mount 800mm to 810mm above floor level.







CF 197 DS RH

CF 197 WT LH

CF 197 WT RH

Drawn LH (Left Hand)

Suits Backrest installation

Diamond Shur-Grip®

CLAM FLANGE®

White

White

CLAM FLANGE® - AMBULANT & TOILET GRAB RAILS







Clam Flange® regular 32mm grab rail, fabricated from 304 stainless steel with 78mm pre-formed domed Clam Flange®. Manufactured to comply with clause 17 of AS 1428.1-2009 for Design and Construction. For horizontal fixing of grab rails, mount 800mm to 810mm above floor level.



TD 001	TD 001 00			L
TR 031	TR 031 SS	Code	Finish	Features
450mm x 450mm		Reversible		
43011111 X 43011111			Satin Supreme™	450mm x 450mm
P	Т	CF 454 SS		Complies with requirements
		CF 454 PS	Polish Supreme™	of AS 1428.1-2009 for water closets. Stainless steel fixing screws supplied.
55	450	CF 454 DS	Diamond Shur-Grip®	Other Colours Available
		CF 454 WT	White	
450	_			AS 1428.1
	Drawn LH (Left Hand)			(CLAM FLANGE®) AMBULANT COMPLIANT COMPLIANT
	or ambulant disabilities			CLAM FLANGE® COMPLIANT COMPLIANT
400mm x 600mm	_	Please specify l	eft or right hand	
		CF 046 SS LH	Satin Supreme™	400mm x 600mm
		CF 046 SS RH	Satin Supreme™	Stainless steel fixing screws supplied. Other Colours Available
	600	CF 046 PS LH	Polish Supreme™	Other Golda's Available
55		CF 046 PS RH	Polish Supreme™	
	\perp	CF 046 DS LH	Diamond Shur-Grip®	
400		CF 046 DS RH	Diamond Shur-Grip®	
		CF 046 WT LH	White	
	Drawn LH (Left Hand)	CF 046 WT RH	White	CLAM FLANGE®
600mm x 600mm	, ,	Please specify I	eft or right hand	
		CF 606 SS LH	Satin Supreme™	600mm x 600mm
	? *⊤	CF 606 SS RH	Satin Supreme™	Stainless steel fixing screws supplied.
	l.	CF 606 PS LH	Polish Supreme™	Other Colours Available
55	600	CF 606 PS RH	Polish Supreme™	
	,	CF 606 DS LH	Diamond Shur-Grip®	
265		CF 606 DS RH	Diamond Shur-Grip®	
600		CF 606 WT LH	White	
	Drawn LH (Left Hand)	CF 606 WT RH	White	(CLAM FLANGE®)
960mm x 600mm	Drawii Ln (Leit naiiu)		eft or right hand	
900IIIII X 000IIIIII		CF 966 SS LH	Satin Supreme™	960mm x 600mm
	? * ⊤			Complies with requirements of
, c		CF 966 SS RH	Satin Supreme TM	AS 1428.1-2009 for water closets.
237	600	CF 966 PS LH	Polish Supreme™	Stainless steel fixing screws supplied. Other Colours Available
		CF 966 PS RH	Polish Supreme™	
625		CF 966 DS LH	Diamond Shur-Grip®	AS 1428.1 AS 1428.1
960 335		CF 966 DS RH	Diamond Shur-Grip®	(5) (S)
	D	CF 966 WT LH	White	DIMENSIONAL PAPER ZONE
	Drawn LH (Left Hand)	CF 966 WT RH	White	CLAM FLANGE® COMPLIANT COMPLIANT
1030mm x 600mm Please specify left or right hand				
1	_	CF 106 SS LH	Satin Supreme™	1030mm x 600mm Complies with requirements of
-6		CF 106 SS RH	Satin Supreme™	AS 1428.1-2009 for water closets.
P1	600	CF 106 PS LH	Polish Supreme™	Stainless steel fixing screws supplied.
		CF 106 PS RH	Polish Supreme™	Other Colours Available
695		CF 106 DS LH	Diamond Shur-Grip®	AS 1428.1 AS 1428.1
1030 335		CF 106 DS RH	Diamond Shur-Grip®	(5) (S)
	Drawn LH (Left Hand)	CF 106 WT LH	White	DIMENSIONAL PAPER ZONE
Note: Horizontal flange connec		CF 106 WT RH	White	CLAM FLANGE® COMPLIANT COMPLIANT
1110mm x 1030mm x 600mm		Please specify l		
	A -	CE 116 CC LU	Catin CupromoTM	1110mm v 1020mm v 600mm centre to well corner



	Please specify le	eft or right hand
	CF 116 SS LH	Satin Supreme™
	CF 116 SS RH	Satin Supreme™
	CF 116 PS LH	Polish Supreme™
	CF 116 PS RH	Polish Supreme™
	CF 116 DS LH	Diamond Shur-Grip®
	CF 116 DS RH	Diamond Shur-Grip®
	CF 116 WT LH	White
	CF 116 WT RH	White
ī		

1110mm x 1030mm x 600mm centre to wall corner Complies with requirements of AS 1428.1-2009 for water closets. Stainless steel fixing screws supplied. **Other Colours Available**









CLAM FLANGE® - CORNER GRAB RAILS

Clam Flange® regular 32mm grab rail, fabricated from 304 stainless steel with 78mm pre-formed domed Clam Flange®. Manufactured to comply with clause 17 of AS 1428.1-2009 for Design and Construction. For horizontal fixing of grab rails, mount 800mm to 810mm above floor level.






1100

CLAM FLANGE® - SHOWER RECESS GRAB RAILS

应 Clam Flange® regular 32mm grab rail, fabricated from 304 stainless steel with 78mm pre-formed domed Clam Flange®. Manufactured to comply with clause 17 of AS 1428.1-2009 for Design and Construction. For horizontal fixing of grab rails, mount 800mm to 810mm above floor level.







180

829 1000 Drawn RH (Right Hand)

Drawn LH (Left Hand)

820

	i ioaso	Specify	ort or right hand
-	CF 711	SS LH	Satin Supreme™
	CF 711	SS RH	Satin Supreme™
1100	CF 711	PS LH	Polish Supreme™
1100	CF 711	PS RH	Polish Supreme™
	CF 711	DS LH	Diamond Shur-Grip®
	CF 711	DS RH	Diamond Shur-Grip®
-	CF 711	WT LH	White
	CF 711	WT RH	White

TO SUIT CORNER SHOWER RECESS

760mm x 1000mm x 1100mm centre to wall corner grab rail. Complies with AS 1428.1-2009 Figure 47 (b) for three sided shower recess. Stainless steel fixing screws supplied. Other Colours Available





PREMIUM - HYGIFNIC SFAI®





Hygienic Seal® Grab Rails - Independence with Style

When health and hygiene matter most, Hygienic Seal® grab rails lead the healthcare industry with Con-Serv's own, innovation cove designed Thermoplastic Elastomer (TPE) fitted flange seal that firms to the rail wall and when installed prevents grime, such as soap scum, body fluids, ointments and aqueous based fluids accumulating behind the grab rail flange covers and creating possible serious health issues.


Only Con-Serv® Hygienic Seal® Safe-Assist® Grab Rails give this promise. Be most cautious of claims made by imitators.

Con-Serv® Hygienic Seal® Safe-Assist® grab rail collection is fabricated from 32mm x 1.2mm, grade 304, 18/8 stainless steel and assembled with a 50mm, 3 part machined brass screw on flange cover with 5 degree radius to comply with clause 17 of AS 1428.1-2009 for Design and Construction and available in the following finishes: Satin Supreme™, Polish Supreme™, Diamond Shur-Grip® and UV Light stabilised colours.


Tested by ETRS Pty Ltd for compliance to 1100 N mass in any position, without any permanent deformation, distortion or loosening of the fastenings. Test report registration number QRN00-2847.

Installation Guide






1. Install straight grab rails including the horizontal section of any grab rails as per AS 1428, 800-810mm from floor to top of rail. Make sure wall surface is flat and free from contaminants.




4. Drill spot marks with 7mm bit. Plug and screw wall mount plate to wall stud, using the 304 stainless steel screws supplied.



2. For STRAIGHT grab rails, position the flange protector guide lugs either vertical or horizontal. For CORNER grab rails, position the guide lugs horizontally "ONLY". Then mark at fixing guide lugs.



5. Fit grab rail into wall mount plate and tighten lock nut firmly.



3. Remove flange protector from grab rail flange, align guide lug marks from step 2 and mark wall through base holes to pinpoint screw holes.

Design Registration number - 311119.



6. Screw flange cover to wall mount plate, to secure the Thermoplastic Elastomer fitted Hydienic Seal®

D. Locking pin

E. Screw mount plate



B. Thermoplastic Elastomer (the seal)

C. Locking nut

A. B. C. D.
ab rails and shower support rails are installed to provi


Grab rails and shower support rails are installed to provide safe support for persons who require assistance in toilets as well as bathrooms and should comply on installation when fixed, to contribute to its ability to withstand the required 1100 Newton force placed upon it. Concrete or brick walls do not present a problem. If a building is constructed with either metal frame or timber it is useful to know the dimensions of the studs and noggings and the place between the studs. Con-Serv® Hygienic Seal® wall mount fitting have two screw holes and can be positioned and fastened at any angle to suit the stud or nogging. TOGGLE BOLTS FIXED INTO TILES, PLASTER BOARD OR OTHER WATERPROOF WALLS ARE NOT SATISFACTORY OR SAFE. Grab rails with Hygienic Seal® flange must be fitted to a solid wall or other firm surface and installed by a qualified trades person.



Drawn LH (Left Hand)

LINEAR - GRAB RAIL OPTIONS

Premium style Safe-Assist® 32mm grab rails. Fabricated from 304 stainless steel and assembled with 50mm brass screw on "T" leg Linear flange with fitted seals which prevent the accumulation of unhealthy grime. The Linear grab rails comply with clause 17 of AS 1428.1-2009 for Design and Construction. Mount horizontal section of rail 800mm to 810mm above the floor.





HYGIENIC SEAL® - STRAIGHT GRAB RAILS

Hygienic Seal® premium 32mm grab rail, fabricated from 304 stainless steel and assembled with 50mm brass screw on flange covers with Thermoplastic Elastomer (TPE) fitted seals. The seals firm to the rail wall and prevent the accumulation of unhealthy grime. The Hygienic Seal® grab rail complies with clause 17 of AS 1428.1-2009 for Design and Construction. Mount grab rail 800mm to 810mm above floor level.

MASE			
	Code	Finish	Features (E
	0000	Timon	Contained
200mm			
	HS 200 SS	Satin Supreme™	200mm Ø to Ø Stainless steel fixing screws supplied.
. 000	HS 200 PS	Polish Supreme™	Other Colours Available
55,200	HS 200 DS	Diamond Shur-Grip®	
	HS 200 WT	White	
C. S. Percel	HS 200 G	Gold	
	110 200 0	Gold	(HYGIENIC SEAL®)
300mm			
30011111	HS 300 SS	Satin Supreme™	300mm Ø to Ø
	HS 300 PS	Polish Supreme™	Stainless steel fixing screws supplied.
200 -		·	Other Colours Available
55 300	HS 300 DS	Diamond Shur-Grip®	
	HS 300 WT	White	
	HS 300 G	Gold	
			HYGIENIC SEAL®
400mm			
	HS 400 SS	Satin Supreme™	400mm Ø to Ø
	HS 400 PS	Polish Supreme™	Stainless steel fixing screws supplied. Other Colours Available
55 400	HS 400 DS	Diamond Shur-Grip®	
	HS 400 WT	White	
	HS 400 G	Gold	
	113 400 d	dolu	(HYGIENIC SEAL®)
450mm			(ITGILING SLAL)
45011111	HS 450 SS	Catin Cuproma IM	450mm Ø to Ø
		Satin Supreme™	Stainless steel fixing screws supplied.
20	HS 450 PS	Polish Supreme™	Other Colours Available
55 450	HS 450 DS	Diamond Shur-Grip®	
	HS 450 WT	White	
	HS 450 G	Gold	
			HYGIENIC SEAL®
500mm			
	HS 500 SS	Satin Supreme™	500mm Ø to Ø Stainless steel fixing screws supplied.
	HS 500 PS	Polish Supreme™	Other Colours Available
500	HS 500 DS	Diamond Shur-Grip®	
55	HS 500 WT	White	
	HS 500 G	Gold	
			(HYGIENIC SEAL®)
600mm			
	HS 600 SS	Satin Supreme™	600mm Ø to Ø
	HS 600 PS	Polish Supreme™	Stainless steel fixing screws supplied.
-20			Other Colours Available
55	HS 600 DS	Diamond Shur-Grip®	
<	HS 600 WT	White	
	HS 600 G	Gold	
			HYGIENIC SEAL®
700mm			
	HS 700 SS	Satin Supreme™	700mm Ø to Ø Stainless steel fixing screws supplied.
100	HS 700 PS	Polish Supreme™	Other Colours Available
256	HS 700 DS	Diamond Shur-Grip®	
	HS 700 WT	White	
	HS 700 G	Gold	
			(HYGIENIC SEAL®)



HYGIENIC SEAL® - STRAIGHT GRAB RAILS

Hygienic Seal® premium 32mm grab rail, fabricated from 304 stainless steel and assembled with 50mm brass screw on flange covers with Thermoplastic Elastomer (TPE) fitted seals. The seals firm to the rail wall and prevent the accumulation of unhealthy grime. The Hygienic Seal® grab rail complies with clause 17 of AS 1428.1-2009 for Design and Construction. Mount grab rail 800mm to 810mm above floor level.


	Code	Finish	Features
750mm	HS 750 SS HS 750 PS HS 750 DS HS 750 WT HS 750 G	Satin Supreme™ Polish Supreme™ Diamond Shur-Grip® White Gold	750mm Ø to Ø Stainless steel fixing screws supplied. Other Colours Available
900mm	HS 800 SS HS 800 PS HS 800 DS HS 800 WT HS 800 G	Satin Supreme™ Polish Supreme™ Diamond Shur-Grip® White Gold	800mm Ø to Ø Stainless steel fixing screws supplied. Other Colours Available HYGIENIC SEAL®
30011111	HS 900 SS HS 900 PS HS 900 DS HS 900 WT HS 900 SC HS 900 G	Satin Supreme™ Polish Supreme™ Diamond Shur-Grip® White Satin Chrome Gold	900mm Ø to Ø Stainless steel fixing screws supplied. Other Colours Available HYGIENIC SEAL®
1000mm	HS 1000 SS HS 1000 PS HS 1000 DS HS 1000 WT HS 1000 G	Satin Supreme™ Polish Supreme™ Diamond Shur-Grip® White Gold	1000mm Ø to Ø Stainless steel fixing screws supplied. Other Colours Available HYGIENIC SEAL®
1100mm	HS 1100 SS HS 1100 PS HS 1100 DS HS 1100 WT HS 1100 G	Satin Supreme [™] Polish Supreme [™] Diamond Shur-Grip® White Gold	1100mm Ø to Ø Stainless steel fixing screws supplied. Other Colours Available
1200mm	HS 1200 SS HS 1200 PS HS 1200 DS HS 1200 WT HS 1200 G	Satin Supreme™ Polish Supreme™ Diamond Shur-Grip® White Gold	1200mm Ø to Ø Stainless steel fixing screws supplied. Other Colours Available HYGENIC SEAL®

HYGIENIC SEAL® - AMBULANT & TOILET GRAB RAILS

Optional extras: Toilet Roll Holders

Mygienic Seal® premium 32mm grab rail. Fabricated from 304 stainless steel and assembled with 50mm brass screw on flange covers with Thermoplastic Elastomer (TPE) fitted seals. The seals firm to the rail wall and prevent the accumulation of unhealthy grime. The Hygienic Seal® grab rail complies with clause 17 of AS 1428.1-2009 for Design and Construction. Mount horizontal section of rail 800mm to 810mm above floor level.

Code Finish Features 450mm x 450mm Reversible 450mm x 450mm HS 045 SS Satin Supreme™ Stainless steel fixing screws supplied. HS 045 PS Polish Supreme™ Suitable for left or right hand installation. HS 045 DS Diamond Shur-Grip® Other Colours Available White HS 045 WT HYGIENIC SEAL® Drawn LH (Left Hand) 450mm x 700mm Please specify left or right hand HS 457 SS LH Satin Supreme™ 450mm x 700mm 988 Complies with requirements of **HS 457 SS RH** Satin Supreme™ AS 1428.1-2009 for water closets. Stainless steel fixing screws supplied. HS 457 PS LH Polish Supreme™ Other Colours Available Polish Supreme™ HS 457 PS RH 452 HS 457 DS LH Diamond Shur-Grip® AS 1428.1 Diamond Shur-Grip® HS 457 DS RH White HS 457 WT LH Drawn LH (Left Hand) PAPER ZONE COMPLIANT HYGIENIC SEAL® For ambulant disabilities. HS 457 WT RH White 700mm x 700mm Please specify left or right hand HS 077 SS LH Satin Supreme™ 700mm x 700mm 1240 Stainless steel fixing screws supplied. **HS 077 SS RH** Satin Supreme™ **Other Colours Available** HS 077 PS LH Polish Supreme™ Polish Supreme™ HS 077 PS RH 452 Diamond Shur-Grip® HS 077 DS LH Diamond Shur-Grip® 245 HS 077 DS RH HS 077 WT LH White Drawn LH (Left Hand) HYGIENIC SEAL® HS 077 WT RH White 870mm x 700mm Please specify left or right hand HS 877 SS LH Satin Supreme™ 870mm x 700mm 1408 Complies with requirements of HS 877 SS RH Satin Supreme™ AS 1428.1-2009 for water closets. Stainless steel fixing screws supplied. HS 877 PS LH Polish Supreme™ Other Colours Available HS 877 PS RH Polish Supreme™ 452 **HS 877 DS LH** Diamond Shur-Grip® AS 1428.1 **HS 877 DS RH** Diamond Shur-Grip® 245 D HS 877 WT LH White PAPER ZONE COMPLIANT HYGIENIC SEAL® Drawn LH (Left Hand) HS 877 WT RH White 940mm x 700mm Please specify left or right hand 947 SS LH Satin Supreme™ 940mm x 700mm 1478 Complies with requirements of



1		HS
\		HS
-		HS
452	452	HS
	HS	
_	L	HS
eft Hand)		HS
		ПС

947 SS RH Satin Supreme™ Polish Supreme™ 947 PS LH 947 PS RH Polish Supreme™ Diamond Shur-Grip® 947 DS LH 947 DS RH Diamond Shur-Grip® 947 WT LH White

AS 1428.1-2009 for water closets.





Stainless steel fixing screws supplied.





HS 947 WT RH	White
Please specify I	eft or right hand
HS 197 SS LH	Satin Supreme™
HS 197 SS RH	Satin Supreme™
HS 197 PS LH	Polish Supreme™
HS 197 PS RH	Satin Supreme™
HS 197 DS LH	Diamond Shur-Grip®
HS 197 DS RH	Diamond Shur-Grip®
HS 197 WT LH	White
HS 197 WT RH	White

1110mm x 940mm x 700mm centre to wall corner Complies with requirements of AS 1428.1-2009 for water closets. Stainless steel fixing screws supplied. Other Colours Available







HYGIENIC SEAL® - AMBULANT & TOILET GRAB RAILS





Hygienic Seal® premium 32mm grab rail. Fabricated from 304 stainless steel and assembled with 50mm brass screw on flange covers with Thermoplastic Elastomer (TPE) fitted seals. The seals firm to the rail wall and prevent the accumulation of unhealthy grime. The Hygienic Seal® grab rail complies with clause 17 of AS 1428.1-2009 for Design and Construction. Mount horizontal section of rail 800mm to 810mm above floor level.

		Code	Finish	Features	
450mm x 450mm		Please specify le	eft or right hand		
		HS 454 SS LH	Satin Supreme™	450mm x 450mm	
	P	HS 454 SS RH	Satin Supreme™	Complies with requirements of AS 1428.1-2009 for water closets.	
		HS 454 PS LH	Polish Supreme™	Stainless steel fixing screws supplied.	
55	450	HS 454 PS RH	Polish Supreme™	Other Colours Available	
~)	HS 454 DS LH	Diamond Shur-Grip®	AS 1428.1 AS 1428.1	
115 33	5	HS 454 DS RH	Diamond Shur-Grip®		
450		HS 454 WT LH	White		
Drawn LH (Left Hand)	For ambulant disabilities	HS 454 WT RH	White	(HYGIENIC SEAL®) AMBULANT COMPLIANT COMPLIANT	
400mm x 600mm	Tor ambulant disabilities	Please specify le			
40011111 X 00011111	2	HS 046 SS LH	Satin Supreme™	400mm x 600mm	
	(* ⊤	HS 046 SS RH	Satin Supreme™	Stainless steel fixing screws supplied.	
		HS 046 PS LH	Polish Supreme™	Other Colours Available	
55	600	HS 046 PS RH	Polish Supreme™		
٠)	HS 046 DS LH	Diamond Shur-Grip®		
65 335	_	HS 046 DS RH	Diamond Shur-Grip®		
400		HS 046 WT LH	White		
Drawn LH (Left Hand)		HS 046 WT RH	White	HYGIENIC SEAL®	
600mm x 600mm		Please specify le			
OOOHIII X OOOHIIII		HS 606 SS LH	Satin Supreme™	600mm x 600mm	
	<i>p</i> ⊤	HS 606 SS RH	Satin Supreme™	Stainless steel fixing screws supplied.	
		HS 606 PS LH	Polish Supreme™	Other Colours Available	
55.	600	HS 606 PS RH	Polish Supreme™		
		HS 606 DS LH	Diamond Shur-Grip®		
		HS 606 DS RH	Diamond Shur-Grip®		
	335	HS 606 WT LH	White		
Drawa III (Left Hand)		HS 606 WT RH	White	HYGIENIC SEAL®	
Drawn LH (Left Hand) 960mm x 600mm		Please specify le			
300mm x 000mm	8	HS 966 SS LH	Satin Supreme™	960mm x 600mm	
	βT	HS 966 SS RH	Satin Supreme™	Complies with requirements of	
		HS 966 PS LH	Polish Supreme™	AS 1428.1-2009 for water closets. Stainless steel fixing screws supplied.	
55	55	HS 966 PS RH	Polish Supreme™	Other Colours Available	
		HS 966 DS LH	Diamond Shur-Grip®	AS 1428.1 AS 1428.1	
625		HS 966 DS RH	Diamond Shur-Grip®	AS 1428.1	
960	335	HS 966 WT LH	White	6 9	
Drawn LH (Left Hand)	1	HS 966 WT RH	White	HYGIENIC SEAL® DIMENSIONAL COMPLIANT PAPER ZONE COMPLIANT	
1030mm x 600mm		Please specify le			
TOSOIIIII X OOOIIIIII	» ⊤	HS 106 SS LH	Satin Supreme™	1030mm x 600mm	
	and the second	HS 106 SS RH	Satin Supreme™	Complies with requirements of	
	600	HS 106 PS LH	Polish Supreme™	AS 1428.1-2009 for water closets. Stainless steel fixing screws supplied.	
	55,	HS 106 PS RH	Polish Supreme™	Other Colours Available	
		HS 106 DS LH	Diamond Shur-Grip®	AS 1428.1 AS 1428.1	
695		HS 106 DS RH	Diamond Shur-Grip®	A5 1426.1	
1030	335	HS 106 WT LH	White	(a)	
Durana III (I off II or all)	Note: Horizontal flange	HS 106 WT RH	White	HYGIENIC SEAL® DIMENSIONAL COMPLIANT COMPLIANT PAPER ZONE COMPLIANT	
Drawn LH (Left Hand) 0	connects directly to rear wall.	Please specify le			
— TTTOMIN X TOOUNIN X OU	ommi 3€ —	HS 116 SS LH	Satin Supreme™	1110mm x 1030mm x 600mm centre to wall corr	ner
	(HS 116 SS RH	Satin Supreme™	Complies with requirements of	
		HS 116 PS LH	Polish Supreme™	AS 1428.1-2009 for water closets. Stainless steel fixing screws supplied.	
50	600	HS 116 PS RH	Polish Supreme™	Other Colours Available	
00		HS 116 DS LH	Diamond Shur-Grip®	AS 1428.1 AS 1428.1	
1110 177	524	ПО 110 DO LП	Diamond Shur Grip®		

HS 116 DS RH

HS 116 WT LH

HS 116 WT RH

335

Drawn LH (Left Hand)

Suits Backrest installation

Diamond Shur-Grip®

HYGIENIC SEAL®

White

White



HYGIENIC SEAL® - CORNER GRAB RAILS

Hygienic Seal® premium 32mm grab rail. Fabricated from 304 stainless steel and assembled with 50mm brass screw on flange covers with Thermoplastic Elastomer (TPE) fitted seals. The seals firm to the rail wall and prevent the accumulation of unhealthy grime. The Hygienic Seal® grab rail complies with clause 17 of AS 1428.1-2009 for Design and Construction. Mount horizontal section of rail 800mm to 810mm above floor level.






HYGIENIC SEAL® - SHOWER RECESS GRAB RAILS

炣 Hygienic Seal® premium 32mm grab rail. Fabricated from 304 stainless steel and assembled with 50mm brass screw on flange covers with Thermoplastic Elastomer (TPE) fitted seals. The seals firm to the rail wall and prevent the accumulation of unhealthy grime. The Hygienic Seal® grab rail complies with clause 17 of AS 1428.1-2009 for Design and Construction. Mount horizontal section of rail 800mm to 810mm above floor level.





1100	Drawn RH (Right Hand)	
	Orawn LH (Left Hand)	

ricase	specify it	art or right hand
HS 711	SS LH	Satin Supreme™
HS 711	SS RH	Satin Supreme™
HS 711	PS LH	Polish Supreme™
HS 711	PS RH	Polish Supreme™
HS 711	DS LH	Diamond Shur-Grip®
HS 711	DS RH	Diamond Shur-Grip®
HS 711	WT LH	White
HS 711	WT RH	White

Complies with AS 1428.1-2009 Figure 47 (b) for three sided shower

Stainless steel fixing screws supplied. **Other Colours Available**







HYGIENIC SEAL® - GRAB RAIL WITH TOWEL RAIL

Hygienic Seal® premium 32mm grab rail with 19mm towel rail. Fabricated from 304 stainless steel and assembled with 50mm brass screw on flange covers with Thermoplastic Elastometer (TPE) fitted seals. The seals firm to the rail wall and prevent the accumulation of unhealthy grime. The Hygienic Seal® grab rail complies with clause 17 of AS 1428.1-2009 for Design and Construction. Mount horizontal section of rail 800mm to 810mm above floor level.

"D" SHAPE and "U" SHAPE




HYGIENIC SEAL®

screws supplied

HYGIENIC SEAL® - GRAB RAIL WITH TOILET ROLL HOLDER Hygienic Seal® premium 32mm grab rail with 19mm, 165mm x 85mm toilet roll holder with end cap. Fabricated

Hygienic Seal® premium 32mm grab rail with 19mm, 165mm x 85mm toilet roll holder with end cap. Fabricated from 304 stainless steel and assembled with 50mm brass screw on flange covers with Thermoplastic Elastometer (TPE) fitted seals. Complies with clause 17 of AS 1428.1-2009 for Design and Construction. Mount horizontal section of rail 800mm to 810mm above floor level.






SAFE-ASSIST® TILTLOCK® FOLDING GRAB RAILS

The Safe-Assist® Tiltlock® folding grab rail automatically locks when in the horizontal position and locks vertically as a support grab rail for standing patients. Fabricated with a chromed brass button release base housing, a solid brass concealed 4 fixed wall "T" mount bracket and 304 stainelss steel tube. The Tiltlock® complies with clause 17 of 1428.1-2009 for Design and Construction. Tested by ANTL, to 280kg. Test report 4197.12 - 22.07.2013.

GRAB RAILS SHOULD BE MOUNTED SO THAT THE TOP OF THE RAIL IS 800 - 810mm ABOVE THE FLOOR.



SAFE-ASSIST® SWINGLOCK® AND SIDE ASSIST RAIL-WAYS®

Safe-Assist® dual bar, side swing grab rail for parallel cisterns and water closet designs when the toilet is installed in a corner requiring a grab rail each side of the pan. The Swinglock® Hexagon F&M Lift/drop locking system eliminates bar sway, locks 45° left or right hand and locks 90° parallel with the wall when not required.


The Swinglock® grab rails are in compliance with the general requirements for applications in hospitals, homes for the elderly and nursing homes. For water closest where the Swinglock® is not suitable, we recommend the Tiltlock® or Lift-N-Lock™ folding grab rails.







Code



850mm SWINGLOCK® SIDE ASSIST	RAIL
T) .	
960	

SL 850 SS	Satin Supreme™	850mm x 80

Finish

850mm x 805mm dual bar Swinglock® side swing grab rail. Fabricated from 304 stainless steel and assembled with 78mm pre-formed domed Clam Flange®.

Stainless steel fixing screws supplied.

WITH TOILET ROLL HOLDER
SL 850 SS S Satin Supreme™

WITH NURSE CALL HOOK
SL 850 SS H Satin Supreme™



Features

850mm x 800mm x 450mm TWIN ASSIST GRAB RAIL - SUITS EXPOSED & CONCEALED CISTERNS




CF 848 SS	Satin Supreme™

850mm x 800mm x 450mm twin toilet assist grab rail with slide connecting bar to suit exposed and concealed cisterns. Fabricated from 304 stainless steel and assembled with 78mm pre-formed domed Clam Flange®.

Stainless steel fixing screws supplied.



800mm FREE STANDING GRAB RAIL




CF 818 SS	Satin Supreme™

 $800 \text{mm} \times 184 \text{mm}$ FREE STANDING dual support grab rail. Fabricated from 304 stainless steel and assembled with 78 mm pre-formed domed Clam Flange®.

Stainless steel fixing screws supplied.



LIFT-N-LOCK™ 850mm FOLDING GRAB RAIL



LL 850 SS	Satin Supreme™

Lift-N-Lock[™] folding grab rail, locks when in the vertical position only. Does not lock, unlike the Tiltlock® folding grab rail in the horizontal position. Fabricated from 304 stainless steel, the wall fixing plate with 32mm grab rail has 4 exposed screw fixing points.

Stainless steel fixing screws supplied.

EXPOSED FITTINGS



SAFE-ASSIST® FOLDING SHOWER SEATS

Safe-Assist® folding shower seats for persons who suffer from sickness or disablement. Seat frames with tension grip hinge for horizontal and vertical movement are fabricated from 304 stainless steel and secured to the seat deck with concealed 316 stainless steel screws. Seat decks feature tamperproof, sanitary safe, Polar White, Marine grade, UV stabilised, High Density Polyethylene (HDPE) round edge with self draining channels.

SHOWER SEATS SHOULD BE MOUNTED SO THAT THE SEAT DECK IS 470mm to 480mm ABOVE THE FLOOR.

	Code	Finish	Features
ACCESSIBLE SUITES	0000	Timon	1 outul of
960 400	SS 964 SS SS 964 PS	Satin Supreme [™] Polish Supreme [™]	Seat size: 960mm x 400mm shower seat. Assembled with Polar White, UV stabilised, fade resistant, High Density Polyethylene (HDPE) seat deck with self draining channels.
	Leg Extension	(PAIR) 50mm - 200mm	Shower seat complies with the minimum design, strength and dimension requirements of AS 1428.1-2009. Stainless steel fixing screws supplied. MAX. LOAD: 160kg (25 stone)
Suite all standard accessible suites	SS 964 SS LE SS 964 PS LE	Satin Supreme [™] Polish Supreme [™]	AS 1428.1 DIMENSIONAL COMPLIANT Wall Bracket Dimension
Suits all standard accessible suites WHEELCHAIR TRANSFER SEAT			Som Earl
WHEELGHAIN FRANSFER SEAT	SS 964 SS WM	Satin Supreme [™]	Seat size: 960mm x 400mm seat supported by heavy duty Tension Grip hinge brackets. Most suitable for convenient transfer between wheelchair and shower seat. Assembled with Polar White, UV stabilised, fade resistant, High Density Polyethylene (HDPE) seat deck with self draining channels.
960 400			Shower seat complies with the minimum design, strength and dimension requirements of AS 1428.1-2009.
290			Stainless steel fixing screws supplied. MAX. LOAD: 160kg (25 stone) INSTALLATION HEIGHT OF SEAT: 470mm - 480mm
Must be fitted to a solid wall or other firm			AS 1428.1
surface.			DIMENSIONAL COMPLIANT Wall Bracket Dimension
COVED WALLS			
260 400	SS 964 SS CW	Satin Supreme [™]	Seat size: 960mm x 400mm seat with 100mm x 60mm coved plated rear legs for fixing to floor with 10mm front leg Acetyl plugs to suit shower cubical gradient. Assembled with Polar White, UV stabilised, fadd resistant, High Density Polyethylene (HDPE) seat deck with self draining channels.
			Shower seat complies with the minimum design, strength and dimension requirements of AS 1428.1-2009.
480			Stainless steel fixing screws supplied. MAX. LOAD: 160kg (25 stone)
_ T			AS 1428.1
Designed for coved walls - Floor mounted			COMPLIANT Floor Mount Dimension
SLATTED SEAT DECK			
960 400	SS 964 SS ME SS 964 WT ME	Stainless Steel White	Seat size: 960mm x 400mm Seat frame and 3 part slatted seat deck fabricated from 304 stainless steel. Powder coated totally white. Other colours available on request.
480			Shower seat complies with the minimum design, strength and dimension requirements of AS 1428.1-2009. Stainless steel fixing screws supplied. MAX. LOAD: 160kg (25 stone)
			AS 1428.1
Rounded stainless steel safety edge			DIMENSIONAL COMPLIANT Wall Bracket Dimension

STANDARD FIXING - STUD WALLS

- Use the 4 x stainless steel M8 x 75mm coach screws supplied.
- Fix seat with the coach screws into wall studs or nogging.
- Shower seats must be fitted to a solid wall or into stud construction
- Wall surface must be flat.

STANDARD FIXING - MASONRY WALLS

- Use the 4 x stainless steel M8 x 75mm coach screws and plugs supplied.
- Fix seat with wall plugs and coach screws onto wall.
- The installer should ensure that the nature of the wall will provide a firm fixing for all screws supporting the shower seat.



SAFE-ASSIST® PURPOSE BUILT SHOWER SEATS

Safe-Assist® folding shower seats for persons who suffer from sickness or disablement. Seat frames with tension grip hinge for horizontal and vertical movement are fabricated from 304 stainless steel and secured to the seat deck with concealed 316 stainless steel screws. Seat decks feature tamperproof, sanitary safe, Polar White, Marine grade, UV stabilised, High Density Polyethylene (HDPE) round edge with self draining channels.

SHOWER SEATS SHOULD BE MOUNTED SO THAT THE SEAT DECK IS 470mm to 480mm ABOVE THE FLOOR.

	Code	Finish	Features	Ŀ
FOR AREAS NOT STRICTLY DISA	SS 604 SS	Satin Supreme™	Seat size: 600mm x 400mm Grade 304 stainless steel frame	
	SS 604 PS SS 604 SS ME	Polish Supreme [™] Stainless Steel	with Polar White High Density Polyethylene (HDPE) seat deck with self draining channels.	190 350
480			Stainless steel fixing screws supplied.	100
<u> </u>			MAX. LOAD: 160kg (25 stone)	Wall Bracket Dimension
NEW ZEALAND STANDARDS NZS		Catin Consessa TM	Cost size, 200mm v 450mm	<u>-</u>
800	SS 845 SS SS 845 PS	Satin Supreme [™] Polish Supreme [™]	Seat size: 800mm x 450mm Grade 304 stainless steel frame with Polar White High Density Polyethylene (HDPE) seat deck with self draining channels.	190 350
480			Stainless steel fixing screws supplied.	700
			MAX. LOAD: 160kg (25 stone)	Wall Bracket Dimension
CHANGING PLACES SHOWER SE				
960 450	SS 945 SS	Satin Supreme [™]	Seat size: 960mm x 450mm Grade 304 stainless steel frame with Polar White High Density Polyethylene (HDPE) seat deck with self draining channels.	190 350
480			Stainless steel fixing screws supplied.	100
1 1			MAX. LOAD: 160kg (25 stone)	Wall Bracket Dimension
BARIATRIC SEAT FOR AREAS NO	T CTRICTLY DICARLED			
	JI STRICTLY DISABLED			
500	SS 965 SS	Satin Supreme [™]	LARGE SHOWER SEAT WITH ADDITIONAL ACCEPT HEAVIER LOAD.	CENTRE SUPPORT TO
960 500		Satin Supreme [™]	ACCEPT HEAVIER LOAD. Seat size: 960mm x 500mm wide BARIATRIC seat with centre legs so as to take more weight. Assembled with Polar White, UV stabilised, fade resistant, High Density Polyethylene (HDPE) seat deck	CENTRE SUPPORT TO
960		Satin Supreme [™]	ACCEPT HEAVIER LOAD. Seat size: 960mm x 500mm wide BARIATRIC seat with centre legs so as to take more weight. Assembled with Polar White, UV stabilised, fade resistant, High Density Polyethylene (HDPE) seat deck with self draining channels. Stainless steel fixing screws	CENTRE SUPPORT TO
480		Satin Supreme [™]	ACCEPT HEAVIER LOAD. Seat size: 960mm x 500mm wide BARIATRIC seat with centre legs so as to take more weight. Assembled with Polar White, UV stabilised, fade resistant, High Density Polyethylene (HDPE) seat deck with self draining channels.	
Bariatric seat - Designed for heavier loads	SS 965 SS		ACCEPT HEAVIER LOAD. Seat size: 960mm x 500mm wide BARIATRIC seat with centre legs so as to take more weight. Assembled with Polar White, UV stabilised, fade resistant, High Density Polyethylene (HDPE) seat deck with self draining channels. Stainless steel fixing screws supplied.	
Bariatric seat - Designed for heavier	SS 965 SS	DISABLED	ACCEPT HEAVIER LOAD. Seat size: 960mm x 500mm wide BARIATRIC seat with centre legs so as to take more weight. Assembled with Polar White, UV stabilised, fade resistant, High Density Polyethylene (HDPE) seat deck with self draining channels. Stainless steel fixing screws supplied. MAX. LOAD: 200kg (32 stone)	Wall Bracket Dimension
Bariatric seat - Designed for heavier loads	SS 965 SS		ACCEPT HEAVIER LOAD. Seat size: 960mm x 500mm wide BARIATRIC seat with centre legs so as to take more weight. Assembled with Polar White, UV stabilised, fade resistant, High Density Polyethylene (HDPE) seat deck with self draining channels. Stainless steel fixing screws supplied.	Wall Bracket Dimension ED SHOWER ENCLOSURE DE ENOUGH TO
Bariatric seat - Designed for heavier loads SHOWER SEAT FOR LIMITED WA	SS 965 SS	DISABLED	ACCEPT HEAVIER LOAD. Seat size: 960mm x 500mm wide BARIATRIC seat with centre legs so as to take more weight. Assembled with Polar White, UV stabilised, fade resistant, High Density Polyethylene (HDPE) seat deck with self draining channels. Stainless steel fixing screws supplied. MAX. LOAD: 200kg (32 stone) DESIGNED FOR OPPOSING WALL OPEN END AND SITUATIONS WHERE A WALL IS NOT WI ACCOMMODATE PRIOR ART FOLDABLE SEA' Seat size: Side lift, 600mm x 450mm shower seat, assembled with Polar White, UV stabilised, fade resistant, High Density Polyethylene (HDPE) seat deck with self draining channels.	Wall Bracket Dimension ED SHOWER ENCLOSURE DE ENOUGH TO
Bariatric seat - Designed for heavier loads SHOWER SEAT FOR LIMITED WA	SS 965 SS	DISABLED	ACCEPT HEAVIER LOAD. Seat size: 960mm x 500mm wide BARIATRIC seat with centre legs so as to take more weight. Assembled with Polar White, UV stabilised, fade resistant, High Density Polyethylene (HDPE) seat deck with self draining channels. Stainless steel fixing screws supplied. MAX. LOAD: 200kg (32 stone) DESIGNED FOR OPPOSING WALL OPEN END AND SITUATIONS WHERE A WALL IS NOT WI ACCOMMODATE PRIOR ART FOLDABLE SEAT Seat size: Side lift, 600mm x 450mm shower seat, assembled with Polar White, UV stabilised, fade resistant, High Density Polyethylene (HDPE) seat deck with self draining channels. Stainless steel fixing screws supplied.	Wall Bracket Dimension ED SHOWER ENCLOSURE DE ENOUGH TO TS.
Bariatric seat - Designed for heavier loads SHOWER SEAT FOR LIMITED WA	SS 965 SS ALL AREAS NOT STRICTLY SS 645 SS	DISABLED	ACCEPT HEAVIER LOAD. Seat size: 960mm x 500mm wide BARIATRIC seat with centre legs so as to take more weight. Assembled with Polar White, UV stabilised, fade resistant, High Density Polyethylene (HDPE) seat deck with self draining channels. Stainless steel fixing screws supplied. MAX. LOAD: 200kg (32 stone) DESIGNED FOR OPPOSING WALL OPEN END AND SITUATIONS WHERE A WALL IS NOT WI ACCOMMODATE PRIOR ART FOLDABLE SEA' Seat size: Side lift, 600mm x 450mm shower seat, assembled with Polar White, UV stabilised, fade resistant, High Density Polyethylene (HDPE) seat deck with self draining channels.	Wall Bracket Dimension ED SHOWER ENCLOSURE DE ENOUGH TO TS. Wall Bracket Dimension

STANDARD FIXING - STUD WALLS

- Use the 4 x stainless steel M8 x 75mm coach screws supplied.
- Fix seat with the coach screws into wall studs or nogging.
- \bullet Shower seats must be fitted to a solid wall or into stud construction
- Wall surface must be flat.

STANDARD FIXING - MASONRY WALLS

- Use the 4 x stainless steel M8 x 75mm coach screws and plugs supplied.
- Fix seat with wall plugs and coach screws onto wall.
- The installer should ensure that the nature of the wall will provide a firm fixing for all screws supporting the shower seat.



Safe-Assist® Backrests for Healthcare Applications

The Safe-Assist® Backrest, a support device for toilets, bidets and the like, introduced into the Australian Standard for Access and Mobility to comply with the changing requirements for sanitary facilities.

The Safe-Assist® Backrest provides a support that improves the comfort of using a toilet while simultaneously providing an acceptable level of safety for disabled, aged and infirmed.

Con-Serv® patented Safe-Assist® Backrest options as shown are compatible with all cisterns. But due to the different dimensions in cistern design, it is essential to select the correct backrest option to comply with the Australian Access and Mobility Standard AS 1428.1-2009 for single (Figure 52 of

AS 1428.1-2009) or combined (Figure 50 of AS 1428.1-2009) sanitary compartments.

Tested by the Australian National Testing Laboratories Pty Ltd (ANTL) as outlined in clause 15.2.4 Backrest of AS 1428.1-2009, careful selection from the Con-Serv® Safe-Assist® Backrest range will ensure full compliance with the Australian Standards requirement. Floor mount Backrest test report – 3104.11 and Wall Mount Backrest test report – 3411.11

For further information, refer to the Safe-Assist® Backrest Suitability Guide or contact our Technical Product Adviser on the Priority Phone Number – 1300 467 322.

Safe-Assist® Backrest Options



Suits all standard accessible suites. Ideally suited to applications when fastening to rear wall is not an option. E.g. vinyl walls or insufficient bracing.



Model - BR 400 PATENT NUMBER 2010101409

Adjusts to suit cisterns from 340mm to 476mm width, while still allowing the unimpeded installation and access to other grab rails at side of pan as per requirements of AS 1428.1-2009 (fig 42).



Model - BR 440
PATENT NUMBER 2010101409

Flexible installation left or right side of cisterns from 340mm to 476mm width and includes an additional 450mm grab rail extension as per requirements of AS 1428.1-2009 (fig 42).

SAFE-ASSIST® BACKREST SUITABILITY GUIDE	BR 395	BR 400	BR 440
Sanitary Compartment with Conventional Pan	•	•	•
Sanitary Compartment with Wall Faced Pan		•	•
Sanitary Compartment with Shower and Conventional Pan	•	•	
Sanitary Compartment with Shower and Wall Faced Pan		•	

SAFE-ASSIST® - BACKREST



Safe-Assist® Backrest support for single toilet suites and combined PWD sanitary compartments. Robust designed 32mm grade 304 stainless steel Backrest. Fabricated with a choice of 78mm domed Clam Flange® or 50mm Hygienic Seal® flange cover. The Safe-Assist® Backrest features a 96° tamperproof, sanitary safe, Polar White, UV stabilised High Density Polyethylene (HDPE) rounded edge back support.

Complies as per the requirements of AS 1428.1-2009 section 15.2.4-BACKREST.








HYGIENIC SEAL®

BR 400 SS HS Satin Supreme™ BR 400 PS HS Polish Supreme™

- · Also suitable for concealed cisterns
- · Stainless steel fixing screws supplied.




WALL MOUNTED BACKREST WITH 450 mm EXTENSION








- **CLAM FLANGE®** BR 440 SS CF Satin Supreme™ BR 440 PS CF Polish Supreme™
- **HYGIENIC SEAL®** BR 440 SS HS Satin Supreme™ BR 440 PS HS Polish Supreme™
- For single PWD cubicle with conventional pan.
- For single PWD cubicle with wall faced pan.
- The adjustable 450mm extended mount can be installed on the left or right hand side of cistern.
- · Stainless steel fixing screws supplied.





Safe-Assist® Anti-Ligature Grab Rails Bars for High Risk Applications

Specially designed 38mm Anti-Ligature grab rails with barrier fabricated from 304 Stainless steel for use in WC's and other accessible areas to mitigate the possibility of self-harm by patients in psychiatric clinics, hospitals and detention facilities.





SAFE-ASSIST® ANTI-LIGATURE GRAB RAILS

Specially designed 38mm toilet assist Anti-Ligature grab rails with combined vertical and horizontal barriers, fabricated from 304 Stainless steel for use in WC's with concealed or exposed cisterns to mitigate the possibility of self-harm by patients in psychiatric clinics, hospitals and detention facilities.

Generally meets the requirements of AS 1428.1-2009.

			Ę
	Code	Finish	Features
90° ANTI-LIGATURE TOILET ASSIST GRAB RAILS	Please specify I	eft or right hand	
LH (Left Hand) RH (Right Hand)	AL 454 SS LH	Satin Supreme™	450mm x 450mm, 38mm Anti-Ligature grade 304 stainless steel toilet assist grab rail with 30mm combined underpart horizontal square section and 2.5mm centered back plate both continuously welded to rail, giving a 55mm access and grip ability on the grab rail.
90°	AL 454 SS RH	Satin Supreme™	Manufactured with exposed flange. All measurements Ø to Ø of grab rail. Toilet Assist anti-ligature grab rails incorporate a unique open end trough design to assist with cleaning. Tamperproof stainless steel 14# x 1½" POST TORX
For ambulant disabilities			screws supplied. Security hex socket
90° ANTI-LIGATURE TOILET ASSIST GRAB RAILS	Please specify I	eft or right or middle	e fix
LH (Left Hand) 800 800 900 1040 600 900 900 900 960	AL 966 SS LH AL 966 SS RH	Satin Supreme™ Satin Supreme™	960mm x 600mm, 38mm Anti-Ligature grade 304 stainless steel toilet assist grab rail with 30mm combined underpart horizontal square section and 2.5mm centered back plate both continuously welded to rail, giving a 55mm access and grip ability on the grab rail. Manufactured with exposed flange. All measurements Ø to Ø of grab rail. Toilet Assist Anti-Ligature grab rails incorporate a unique open end trough design to assist with cleaning. Tamperproof stainless steel 14# x 1½" POST TORX screws supplied.
For ambulant disabilities 1040	1		Security hex socket
ANTI-LIGATURE SHOWER KITS			
Load Senstive Handset Cradle	AL 01806 CW AL 01806 C	Chrome/White Antimicrobial Chrome Chrome/White	Applying a force of 10kg or more to the installed shower kit will trigger the release mechanism of the hose from the elbow and disengage the load sensitive handset cradle from the grab rail, thereby mitigating the possibility of self-harm. Anti-Ligature Shower Kit includes: • White Acetal 38mm load sensitive handset cradle for shower support and height adjustment • ABS chrome Hosfab® or white Antimicrobial single function shower with rub-clean spray diffusor
		Antimicrobial	PVC 1.5m chrome Silverflex® or white
Elbow with Force Release Mechanism	AL 01809 C	Chrome	Antimicrobial hose with ½" BSP swivel conical nut Chrome DR Brass Anti-Ligature wall outlet elbow featuring force release mechanism Full pattern spray 3 Star 9L/min rated as per WELS licence number 0046 **KIT 9 option includes AL 900 SS VL grab rail
AL 01809 C (KIT 9) Complete with Anti-Ligature 900mm grab rail			Load Senstive Handset Cradle HC 038
900Hilli giab tali			WATER ATING WATER



HYGIENIC SEAL® MULTI-PURPOSE FIXING SYSTEM

Multi-purpose fixing system for Con-Serv®, Safe-Assist® grab rails. Designed for installation of the grab rails on toilet partitions and timber panelling. Three models available for 10mm - 14mm, 15mm - 19mm and 30mm - 34mm thick toilet Partitioning Panels.

Match with Con-Serv® tamperproof Hygienic Seal® Blank End Flange model HS 032 C BF, for a single sided application. Match with the same Hygienic Seal® grab rail for a back to back installation. Generally meets the requirements of AS 1428.1-2009.



	Code	Features
HYGIENIC SEAL® SINGLE SIDED SYSTEM		SINGLE SIDED INSTALLATION PROCEDURE
partition thread tube M5 x 10mm CSK screw tamperproof blank end flange Grab Rail Wall Mount Plates	HS 032 C BE10 suits 10mm - 14mm partition HS 032 C BE15 suits 15mm - 19mm partition HS 032 C BE30 suits 30mm - 34mm partition	 Single sided requires only one (1) grab rail Position grab rail as required and mark fixing holes Drill 6.5mm holes through panel at fixing point Insert internally threaded mounting tubes into holes Partially attach WALL MOUNT PLATE to one side of panel with screws supplied Fit additional WALL MOUNT PLATE to opposite side with screws supplied Tighten both sets of screws until plates are firm Screw tamperproof BLANK END FLANGE to exposed WALL MOUNT PLATE and tighten grub screw with hex key supplied Finally, install the grab rail as per the Hygienic Seal® fixing instructions SINGLE SIDED KIT INCLUDES: 2 HS 032 B MP wall mount plates 2 HS 032 C BF blank end flanges 4 Internal thread tubes 8 M5 x 10mm CSK 304 screws
HYGIENIC SEAL® BACK TO BACK SYSTEM		BACK TO BACK INSTALLATION PROCEDURE
partition internal thread tube M5 x 10mm CSK screw CSK screw Grab Rail Wall Mount Plates	HS 032 B BB10 suits 10mm - 14mm partition HS 032 B BB15 suits 15mm - 19mm partition HS 032 B BB30 suits 30mm - 34mm	 Double sided Back to Back requires 2 grab rails Position one grab rail as required and mark fixing holes Drill 6.5mm holes through panel at fixing points Insert internally threaded mounting tubes into holes Partially attach WALL MOUNT PLATE to one side of panel with screws provided Attach other WALL MOUNT PLATE to opposite side with screws supplied Tigthen both sets of screws until WALL MOUNT PLATES are firm to the panel Finally, install the grab rails as per the Hygienic Seal® fixing instructions BACK TO BACK KIT INCLUDES: 4 Internal thread tubes 8 M5 x 10mm CSK 304 screws
	suits 30mm - 34mm partition	




Hideaway™ Seat Mount System For PWD seat removal and replacement

Given the impact the Access to Premises Standard 2010 has had on the provision of sanitary facilities in sole occupancy units particularly in Class 3 buildings, the Hideaway™ shower seat fixing system has been designed to allow the flexibility to install a shower seat from the Safe-Assist® Con-Serv® range, achieve the relevant compliances, then conveniently remove and store the seat for the future use if required.

To provide minimal visual intrusion on the affected wall when the seat is removed, the shower seat WALL MOUNT PLATES that remain on the wall are concealed by an attractive chrome tamperproof BLANK END FLANGE.

	Code	Finish	Features	>
SHOWER SEAT WALL MOUNT PLATE				
	HS 032 SS BM	Satin Stainless	Con-Serv® exclusive 50mm x 25mm, 304 stainless steel, external threaded, shower seat boxed tube channel WALL	
M7 PLUG 6 SCREW		Stailless	MOUNT PLATE. Designed to accept the tamperproof internal threaded BLANK END FLANGE when the shower seat is remove	:d
0 x2 x2			from the wall to accommodate non PWD room requirements. Stainless steel screws supplied. PATENT NUMBER: 2014101264	
BLANK END FLANGE				
	HS 032 C BF	Chrome	Con-Serv® exclusive 50mm tamperproof internal threaded BLANK END FLANGE to conceal the shower seat WALL MOUNT	.
			PLATE when the shower seat is removed, but will be required	
To eliminate damage tighten with			to be re-installed at a later date for use in PWD requirement.	
strap spanner			Simply unscrew the BLANK END FLANGE and replace the shower seat with the screws as provided.	

HIDEAWAY™ SEAT MOUNT SYSTEM



FIXING INSTRUCTIONS

- Position shower seat for fixing to wall as per fixing instructions. Mark and drill bolt hole, insert the 10mm nylon wall plug, if installing on a masonry wall. Put aside the
- Position the HS 032 PS BM shower seat WALL MOUNT PLATE on the wall with the centre hole over the seat fixing bolt hole and the two adjacent fixing holes in a vertical direction.
- Spot mark and drill fixing holes with 7mm bit. Plug and screw WALL MOUNT PLATE to wall stud, using the 304 1½" x 10G screws supplied, use wall plugs for masonry walls.
- Place the shower seat legs in the WALL MOUNT PLATE, align the leg and the HS 032 PS BM bolt holes and fix the seat to the wall with the M8 x 75mm hex coach screws supplied.

REMOVAL

- · Remove the shower seat fixing coach screws.
- To ensure a tamperproof installation, with the aid of a strap spanner, screw the HS 032 C BF tamperproof BLANK END FLANGE onto the HS 032 PS BM now exposed WALL MOUNT PLATE and tighten grub screw with hex key supplied.
- Store removed shower seat with the M8 x 75mm coach screws and BLANK END FLANGE hex key together for re-installation.
- MOST IMPORTANT plastic bag and store removed shower seat with the M8 x 75mm coach screws and **BLANK END FLANGE** hex key together for re-installation at its original location.




Hideaway[™] Grab Rail Mount System For PWD Grab Rail removal and replacement

Given the impact to Premises Standard 2010 has had on the provision of sanitary facilities in sole occupancy units particularly in Class 3 buildings, the Hideaway™ Hygienic Seal® removable grab rail system allows the flexibility to remove and re-install PWD Hygienic Seal® grab rails that satisfy the requirements of AS 1428.1-2009. Once compliance has been met, simply remove grab rail, store for future use, and cover the HS 032 B MP WALL MOUNT PLATE with HS 032 C BF BLANK END FLANGE.

The Hideaway™ Hygienic Seal® mount system can also be used in conjunction with all Con-Serv® Hygienic Seal® grab rails, Linear grab rails and Back Rests.






1

original location.

RAIL-WAYS® ACCESSORIES





On-Ser			L
	Code	Finish	Features
GRAB RAIL GLIDE SLIDE HANDSET CRADLE	HC 024 BLC HC 024 GYC HC 024 WT HC 024 SC HC 024 ACG	Black/Chrome Grey/Chrome White Satin/Chrome Colour/Gold	Fastens to 32mm grab rail Clicklock™ claw mechanism ABS construction Simple to clean
GRAB RAIL SOAP DISH HOLDER	SD 032 BLC SD 032 GYC SD 032 WT SD 032 SC SD 032 ACG	Black/Chrome Grey/Chrome White Satin/Chrome Colour/Gold	Fastens to 32mm grab rail ABS construction Simple to clean
GRAB RAIL FLEXIBLE TOILET ROLL HOLDER	TR 031 BLC TR 031 GYC TR 031 WT TR 031 SC TR 031 ACG	Black/Chrome Grey/Chrome White Satin/Chrome Colour/Gold	Fastens to 32mm grab rail ABS construction Simple to clean Fits all 32mm toilet assist grab rails
GRAB RAIL STAINLESS STEEL TOILET ROLL Stainless Steel	TR 031 SS S TR 031 PS S	Satin Supreme™ Polish Supreme™	Stainless steel toilet roll holder FACTORY FITTED
PUSH-PULLME® SHOWER POSITIONING CRA	NDLE WITH ROD PM 932 C	Chrome	Brass Friction Slide Cradle with Push-PullMe® shower height
350 HC 932 - 32mm BRAS			adjustment rod. To comply with requirements of AS 1428.1-2009 for person with disabilities (PWD), an adjustable shower head holder shall be provided to support the shower head and shall allow the graspable portion of the shower head to be positioned at various angles and heights and also allow the graspable portion of the shower head to be located at heights between 1000mm and 1800mm above the plane of the finished floor and allow access and adjustment from a seated position. The Push-PullMe® suits this requirement.
	HC 932 C	Chrome	FACTORY FITTED
PREMIUM 700mm FRICTION SLIDE TRACK (CRADLE & COLLARS		
700	SR 700 C SR 700 WTC SR 700 WTG SR 700 SC SR 700 CG SR 700 G	Chrome White/Chrome White/Gold Satin Completely Chrome/Gold Gold	Brass construction Cradle adjustment for handpiece Smooth slide action Self locking Recommended for those persons with arthritic or grip problems. No locking knob FACTORY FITTED





11-30			
HYGIENIC SEAL® WALL MOUNT PLATE	Code	Finish	Features
	HS 032 B MP	Brass	Hygienic Seal® wall screw mount plate. Designed to rotate screw holes to suit stud or nogging. Stainless steel fixing screws supplied.
HYGIENIC SEAL® FLANGE COVER	HS 032 C FC HS 032 WT FC	Chrome White	50mm Hygienic Seal® flange cover. Follow installation instruction guide, page 32, if replacement is required. The Hygienic Seal® is a thermodynamic product designed to eliminate the risk of bathroom debris getting behind the flange and becoming unsanitary, thereby causing or conveying infection. The Hygienic Seal® is intended to assist in the promotion of hygiene, particularly in environments where this is a critical issue. Other Colours Available Be most cautious of claims made by imitators.
HYGIENIC SEAL® BLANK END FLANGE	HS 032 C BF HS 032 WT BF	Chrome White	Blank end tamperproof flange to cover Hygienic Seal® wall mount plate when the grab rail is removed, but will be required to be re-installed for use in a PWD requirement. Other Colours Available
STAND OFF PLATE	HS 032 PS SP	Polish Supreme™	50mm x 9mm, 304 stainless steel STAND OFF PLATE when installation of Hygienic Seal® grab rail extends above wall tiles and requires all mount brackets to be parallel.
TILTLOCK® "T" MOUNT BRACKET Right hand Left hand	TL 850 NI LHWM TL 850 NI RHWM	Brass/Nickel Plate Brass/Nickel Plate	Concealed 4 fix nickel-plated brass "T" mount bracket secures Tiltlock® to wall. Stainless steel fixing screws supplied.
TILTLOCK® (TPE) "T" MOUNT COVER	TL 850 WT WC	White TPE	Thermo Plastic Elastomer (TPE) mount cover to conceal Tiltlock® brass "T" mount bracket for when project specifications call for provision to be made for fold down rails to be installed at a further time.
TILTLOCK® FLOOR MOUNT UPSTAND			
	TL 850 SS US	Satin Stainless	Stainless steel floor mount upstand for mounting Tiltlock® in Bariatric situations and when wall mounting is not possible. Stainless steel fixing screws supplied.



OPTIONS FOR USE IN 2 WALLED SHOWER ENCLOSURE

3 STAR - 9L/min as per WELS licence number - 0046. Horizontal grab rails should be mounted so that the top of the rail is 800mm to 810mm above the floor level. Rails fitted with Hygienic Seal® flange.



AS/NZS 3662 WMKT 21147 Code Description **OPTION A** ID 01803 C • Independent accessible 1000mm handheld shower/grab rail combination with Push-PullMe® showerhead height AND adjustment rod for seated persons. 1 x HS 700 SS • Requires an additional 700mm grab rail, • The Push-PullMe® allows the graspable portion of the shower head to be positioned at various angles and heights between 1000mm and 1800mm above the floor and 1000 allows access and adjustment from a seated position. • Complies with requirements of AS 1428.1-2009 for persons with disabilities (PWD). · Licenced dual check/non-return valve. Brass Friction Slide Cradle with INDICATIVE IMAGE ONLY Push-PullMe® (Refer to page 56, figure 48 for recommended positioning) HYGIENIC SEAL OPTION B • Independent accessible 700mm x 1100mm, LEFT HAND ID 01820 C LH inverted "T" handheld shower/grab rail combination with Push-PullMe® showerhead, height adjustment rod for seated • The Push-PullMe® allows the graspable portion of the shower head to be positioned at various angles and heights between 1000mm and 1800mm above the floor and allows access and adjustment from a seated position. • Complies with requirements of AS 1428.1-2009 for persons with disabilities (PWD) 1100 · Licenced dual check/non-return valve. Brass Friction INDICATIVE IMAGE ONLY Slide Cradle with (Refer to page 56, figure 48 for Push-PullMe® recommended positioning) 205 700 HYGIENIC SEAL® Drawn LH (Left Hand) **OPTION C** ID 01820 C RH • Independent accessible 700mm x 1100mm, RIGHT HAND inverted "T" handheld shower/grab rail combination with Push-PullMe® showerhead, height adjustment rod for seated persons. • The Push-PullMe® allows the graspable portion of the shower head to be positioned at various angles and heights between 1000mm and 1800mm above the floor and allows access and adjustment from a seated position. • Complies with requirements of AS 1428.1-2009 for persons with disabilities (PWD). · Licenced dual check/non-return valve. 1100 Brass Friction Slide Cradle with INDICATIVE IMAGE ONLY Push-PullMe^o (Refer to page 56, figure 48 for recommended positioning)

700

Drawn RH (Right Hand)

HYGIENIC SEAL®



OPTION A

OPTIONS FOR USE TO SUIT

COMBINED ACCESSIBLE SANITARY COMPARTMENT

3 STAR - 9L/min as per WELS licence number - 0046. Horizontal grab rails should be mounted so that the top of the rail is 800mm to 810mm above the floor level.

Rails fitted with Hygienic Seal® flange.





Code



ID 01803 C
 AND
 1 x HS 1200 SS
 Independent accessible 1000mm handheld shower/grab rail combination to suit Combined Accessible Sanitary Compartment with Push-PullMe® shower head height adjustment rod for seated persons.

Description

- · Requires an additional 1200mm grab rail.
- The Push-PullMe® allows the graspable portion of the shower head to be positioned at various angles and heights between 1000mm and 1800mm above the floor and allows access and adjustment from a seated position.
- Complies with requirements of AS 1428.1-2009 for persons with disabilities (PWD).
- · Licenced dual check/non-return valve.


INDICATIVE IMAGE ONLY (Refer to page 56, figure 48 for recommended positioning)







OPTION B



- ID 01821 C LH
- Independent accessible 1170mm x 1100mm, LEFT HAND inverted "T" handheld shower/grab rail combination to suit Combined Accessible Sanitary Compartment with Push-PullMe® shower head height adjustment rod for seated persons.
- The Push-PullMe® allows the graspable portion of the shower head to be positioned at various angles and heights between 1000mm and 1800mm above the floor and allows access and adjustment from a seated position.
- Complies with requirements of AS 1428.1-2009 for persons with disabilities (PWD).
- Licenced dual check/non-return valve.


INDICATIVE IMAGE ONLY (Refer to page 56, figure 48 for recommended positioning)







OPTION C



ID 01821C RH

- Independent accessible 1170mm x 1100mm, RIGHT HAND inverted "T" handheld shower/grab rail combination to suit Combined Accessible Sanitary Compartment with Push-PullMe® shower head height adjustment rod for seated persons.
- The Push-PullMe® allows the graspable portion of the shower head to be positioned at various angles and heights between 1000mm and 1800mm above the floor and allows access and adjustment from a seated position.
- Complies with requirements of AS 1428.1-2009 for persons with disabilities (PWD).
- Licenced dual check/non-return valve.

INDICATIVE IMAGE ONLY (Refer to page 56, figure 48 for

recommended positioning)

(HYGIENIC SEAL®)









Protecting the world's most valuable liquid asset... water!™